



# YAMAHA



**F40L  
F40N  
F50L  
FT50N  
F60H  
FT60J  
F70B**

## OWNER'S MANUAL

**⚠ Read this manual carefully before operating this outboard motor.**

**6C1-28199-7P-E0**

**Read this manual carefully before operating this outboard motor. Keep this manual onboard in a waterproof bag when boating. This manual should stay with the outboard motor if it is sold.**

# Important manual information

---

EMU25108

## To the owner

Thank you for selecting a Yamaha outboard motor. This Owner's Manual contains information needed for proper operation, maintenance and care. A thorough understanding of these simple instructions will help you obtain maximum enjoyment from your new Yamaha. If you have any question about the operation or maintenance of your outboard motor, please consult a Yamaha dealer.

In this Owner's Manual particularly important information is distinguished in the following ways.



: This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

EWM00782



### **WARNING**

**A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.**

EGM00702

### **NOTICE**

**A NOTICE indicates special precautions that must be taken to avoid damage to the outboard motor or other property.**

### **TIP:**

A TIP provides key information to make procedures easier or clearer.

Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your machine and this manual. If

there is any question concerning this manual, please consult your Yamaha dealer.

To ensure long product life, Yamaha recommends that you use the product and perform the specified periodic inspections and maintenance by correctly following the instructions in the owner's manual. Any damage resulting from neglect of these instructions is not covered by warranty.

Some countries have laws or regulations restricting users from taking the product out of the country where it was purchased, and it may be impossible to register the product in the destination country. Additionally, the warranty may not apply in certain regions. When planning to take the product to another country, consult the dealer where the product was purchased for further information.

If the product was purchased used, please consult your closest dealer for customer re-registration, and to be eligible for the specified services.

### **TIP:**

The F40LET, F40NET, F50LED, F50LET, FT50NET, F60HET, FT60JET, F70BET and the standard accessories are used as a base for the explanations and illustrations in this manual. Therefore some items may not apply to every model.

# Important manual information

---

EMU25123

**F40L, F40N, F50L, FT50N, F60H, FT60J, F70B**

**OWNER'S MANUAL**

**©2025 by Yamaha Motor Co., Ltd.**

**1st Edition, November 2024**

**All rights reserved.**

**Any reprinting or unauthorized use  
without the written permission of**

**Yamaha Motor Co., Ltd.**

**is expressly prohibited.**

**Printed in Japan**

# Table of contents

|                                             |           |                                       |           |
|---------------------------------------------|-----------|---------------------------------------|-----------|
| <b>Safety information .....</b>             | <b>1</b>  | Battery requirements .....            | 16        |
| Outboard motor safety .....                 | 1         | Battery specifications .....          | 16        |
| Propeller .....                             | 1         | Propeller selection .....             | 16        |
| Rotating parts .....                        | 1         | Start-in-gear protection .....        | 17        |
| Hot parts .....                             | 1         | Engine oil requirements .....         | 18        |
| Electric shock .....                        | 1         | Fuel requirements .....               | 18        |
| Power trim and tilt .....                   | 1         | Gasoline .....                        | 18        |
| Engine shut-off cord (lanyard) .....        | 1         | Muddy or acidic water .....           | 19        |
| Gasoline .....                              | 2         | Anti-fouling paint .....              | 19        |
| Gasoline exposure and spills .....          | 2         | Outboard motor disposal               |           |
| Carbon monoxide .....                       | 2         | requirements .....                    | 19        |
| Modifications .....                         | 2         | Emergency equipment .....             | 20        |
| <b>Boating safety .....</b>                 | <b>2</b>  |                                       |           |
| Alcohol and drugs .....                     | 2         | <b>Components .....</b>               | <b>21</b> |
| Personal flotation devices (PFDs) .....     | 2         | Components diagram .....              | 21        |
| People in the water .....                   | 2         | Optional items .....                  | 23        |
| Passengers .....                            | 2         | Fuel tank .....                       | 24        |
| Overloading .....                           | 3         | Fuel joint .....                      | 24        |
| Avoid collisions .....                      | 3         | Fuel gauge .....                      | 24        |
| Collisions with floating or                 |           | Fuel tank cap .....                   | 24        |
| submerged objects .....                     | 3         | Air vent screw .....                  | 24        |
| Weather .....                               | 4         | Yamaha Security System (Y-COP/        |           |
| Passenger training .....                    | 4         | Optional) .....                       | 24        |
| Boating safety publications .....           | 4         | Remote control box .....              | 25        |
| Laws and regulations .....                  | 4         | Remote control lever .....            | 25        |
|                                             |           | Neutral interlock trigger .....       | 25        |
| <b>General information .....</b>            | <b>5</b>  | Neutral throttle lever .....          | 25        |
| Identification numbers record .....         | 5         | Tiller handle .....                   | 26        |
| Outboard motor serial number .....          | 5         | Gear shift lever .....                | 26        |
| Key number .....                            | 5         | Throttle grip .....                   | 26        |
| EC Declaration of Conformity                |           | Throttle indicator .....              | 26        |
| (DoC) .....                                 | 5         | Throttle friction adjuster .....      | 27        |
| CE Marking / UKCA Marking .....             | 6         | Engine shut-off cord (lanyard) and    |           |
| Read manuals and labels .....               | 7         | clip .....                            | 27        |
| Warning labels .....                        | 7         | Engine stop button .....              | 28        |
| Use of your data .....                      | 11        | Main switch .....                     | 28        |
|                                             |           | Steering friction adjuster .....      | 29        |
| <b>Specifications and requirements ....</b> | <b>14</b> | Power trim and tilt switch on         |           |
| Specifications .....                        | 14        | remote control or tiller handle ..... | 29        |
| Installation requirements .....             | 16        | Power trim and tilt switch on         |           |
| Boat horsepower rating .....                | 16        | bottom cowling .....                  | 30        |
| Mounting outboard motor .....               | 16        | Variable trolling RPM switches .....  | 30        |
| Remote control requirements .....           | 16        | Trim tab with anode .....             | 31        |
|                                             |           | Trim rod (tilt pin) .....             | 31        |

# Table of contents

---

|                                                                         |           |                                                                  |    |
|-------------------------------------------------------------------------|-----------|------------------------------------------------------------------|----|
| Tilt lock mechanism .....                                               | 32        | Controls .....                                                   | 48 |
| Tilt support lever for power trim<br>and tilt or hydro tilt model ..... | 32        | Engine shut-off cord (lanyard) .....                             | 48 |
| Cowling lock lever .....                                                | 32        | Engine oil .....                                                 | 48 |
| Flushing device .....                                                   | 32        | Engine .....                                                     | 49 |
| Fuel filter/Water separator .....                                       | 33        | Flushing device .....                                            | 49 |
| Alert indicator .....                                                   | 33        | Installing top cowling .....                                     | 49 |
| <b>Instruments and indicators .....</b>                                 | <b>34</b> | Power trim and tilt system .....                                 | 50 |
| Indicators .....                                                        | 34        | Battery .....                                                    | 50 |
| Low oil pressure-alert indicator .....                                  | 34        | Filling fuel .....                                               | 51 |
| Overheat-alert indicator .....                                          | 34        | Operating engine .....                                           | 52 |
| Digital tachometer .....                                                | 34        | Sending fuel (portable tank) .....                               | 52 |
| Tachometer .....                                                        | 35        | Starting engine .....                                            | 53 |
| Trim meter .....                                                        | 35        | Checks after starting engine .....                               | 55 |
| Hour meter .....                                                        | 35        | Cooling water .....                                              | 55 |
| Low oil pressure-alert indicator .....                                  | 35        | Warming up engine .....                                          | 56 |
| Overheat-alert indicator .....                                          | 36        | Manual start and electric start<br>models .....                  | 56 |
| Digital speedometer .....                                               | 36        | Checks after engine warm up .....                                | 56 |
| Speedometer .....                                                       | 36        | Shifting .....                                                   | 56 |
| Fuel gauge .....                                                        | 37        | Stop switches .....                                              | 56 |
| Trip meter / Clock / Voltmeter .....                                    | 37        | Shifting .....                                                   | 56 |
| Fuel level-alert indicator .....                                        | 38        | Stopping boat .....                                              | 58 |
| Low battery voltage-alert indicator .....                               | 38        | Trolling .....                                                   | 58 |
| 6Y8 Multifunction meters .....                                          | 38        | Adjusting trolling speed .....                                   | 58 |
| <b>Engine control system .....</b>                                      | <b>42</b> | Stopping engine .....                                            | 58 |
| Alert system .....                                                      | 42        | Procedure .....                                                  | 58 |
| Overheat alert .....                                                    | 42        | Trimming outboard motor .....                                    | 59 |
| Low oil pressure alert .....                                            | 43        | Adjusting trim angle (Power trim<br>and tilt) .....              | 60 |
| <b>Installation .....</b>                                               | <b>44</b> | Adjusting trim angle for hydro tilt<br>models .....              | 61 |
| Installation .....                                                      | 44        | Adjusting boat trim .....                                        | 61 |
| Mounting the outboard motor .....                                       | 44        | Tilting up and down .....                                        | 62 |
| <b>Operation .....</b>                                                  | <b>46</b> | Procedure for tilting up (hydro tilt<br>models) .....            | 62 |
| First-time operation .....                                              | 46        | Procedure for tilting up (power trim<br>and tilt models) .....   | 63 |
| Fill engine oil .....                                                   | 46        | Procedure for tilting down (hydro<br>tilt models) .....          | 65 |
| Breaking in engine .....                                                | 46        | Procedure for tilting down (power<br>trim and tilt models) ..... | 65 |
| Getting to know your boat .....                                         | 46        | Shallow water .....                                              | 66 |
| Checks before starting engine .....                                     | 47        | Hydro tilt models .....                                          | 66 |
| Fuel level .....                                                        | 47        | Power trim and tilt models .....                                 | 67 |
| Remove the top cowling .....                                            | 47        |                                                                  |    |
| Fuel system .....                                                       | 47        |                                                                  |    |

# Table of contents

---

|                                          |           |                                  |            |
|------------------------------------------|-----------|----------------------------------|------------|
| Cruising in other conditions .....       | 68        | Emergency starting engine.....   | 100        |
|                                          |           | Treatment of submerged motor ... | 101        |
| <b>Maintenance .....</b>                 | <b>69</b> | <b>INDEX .....</b>               | <b>102</b> |
| Transporting and storing                 |           |                                  |            |
| outboard motor .....                     | 69        |                                  |            |
| Storing outboard motor .....             | 69        |                                  |            |
| Procedure .....                          | 70        |                                  |            |
| Lubrication .....                        | 71        |                                  |            |
| Flushing power unit .....                | 72        |                                  |            |
| Cleaning the outboard motor .....        | 73        |                                  |            |
| Checking painted surface of              |           |                                  |            |
| outboard motor .....                     | 73        |                                  |            |
| Periodic maintenance.....                | 73        |                                  |            |
| Replacement parts .....                  | 74        |                                  |            |
| Severe operating conditions.....         | 74        |                                  |            |
| Maintenance chart 1 .....                | 75        |                                  |            |
| Maintenance chart 2 .....                | 78        |                                  |            |
| Greasing .....                           | 79        |                                  |            |
| Inspecting spark plug .....              | 79        |                                  |            |
| Inspecting idle speed .....              | 80        |                                  |            |
| Changing engine oil .....                | 81        |                                  |            |
| Replacing the engine oil filter .....    | 83        |                                  |            |
| Why Yamalube .....                       | 84        |                                  |            |
| Inspecting wiring and connectors .....   | 84        |                                  |            |
| Checking propeller .....                 | 85        |                                  |            |
| Removing propeller .....                 | 85        |                                  |            |
| Installing propeller .....               | 86        |                                  |            |
| Changing gear oil .....                  | 87        |                                  |            |
| Inspecting and replacing anode(s) ....   | 88        |                                  |            |
| Checking battery (for electric start     |           |                                  |            |
| models).....                             | 89        |                                  |            |
| Connecting the battery .....             | 89        |                                  |            |
| Disconnecting the battery .....          | 90        |                                  |            |
| Storing the battery .....                | 90        |                                  |            |
| <b>Trouble Recovery .....</b>            | <b>91</b> |                                  |            |
| Troubleshooting .....                    | 91        |                                  |            |
| Temporary action in emergency.....       | 94        |                                  |            |
| Impact damage.....                       | 94        |                                  |            |
| Replacing fuse.....                      | 94        |                                  |            |
| Power trim and tilt will not operate.... | 96        |                                  |            |
| Water separator-alert is activated       |           |                                  |            |
| after leaving port .....                 | 96        |                                  |            |
| Starter will not operate .....           | 99        |                                  |            |

# Safety information

---

EMU33623

## Outboard motor safety

Observe these precautions at all times.

EMU36502

### Propeller

People can be injured or killed if they come in contact with the propeller. The propeller can keep moving even when the motor is in neutral, and sharp edges of the propeller can cut even when stationary.

- Stop the engine when a person is in the water near you.
- Keep people out of reach of the propeller, even when the engine is off.

EMU40272

### Rotating parts

Hands, feet, hair, jewelry, clothing, personal flotation device (PFD) straps, etc., can become entangled with internal rotating parts of the engine, resulting in serious injury or death.

Keep the top cowling in place whenever possible. Do not remove or replace the top cowling with the engine running.

Only operate the engine with the top cowling removed according to the specific instructions in the manual. Keep hands, feet, hair, jewelry, clothing, PFD straps, etc., away from any exposed moving parts.

EMU33641

### Hot parts

During and after operation, engine parts are hot enough to cause burns. Avoid touching any parts under the top cowling until the engine has cooled.

EMU33651

### Electric shock

Do not touch any electrical parts while starting or operating the engine. They can cause shock or electrocution.

EMU33662

### Power trim and tilt

Body parts can be crushed between the motor and the clamp bracket when the motor is trimmed or tilted. Keep body parts out of this area at all times. Be sure no one is in this area before operating the power trim and tilt mechanism.

The power trim and tilt switches operate even when the main switch is off. Keep people away from the switches whenever working around the motor.

Never get under the lower unit while it is tilted, even when the tilt support lever is locked. Severe injury could occur if the outboard motor accidentally falls.

EMU33672

### Engine shut-off cord (lanyard)

Attach the engine shut-off cord so that the engine stops if the operator falls overboard or leaves the helm. This prevents the boat from running away under power and leaving people stranded, or running over people or objects.

Always attach the engine shut-off cord to a secure place on your clothing or your arm or leg while operating. Do not remove it to leave the helm while the boat is moving. Do not attach the cord to clothing that could tear loose, or route the cord where it could become entangled, preventing it from functioning.

Do not route the cord where it is likely to be accidentally pulled out. If the cord is pulled during operation, the engine will shut off and

you will lose most steering control. The boat could slow rapidly, throwing people and objects forward.

EMU33811

## Gasoline

**Gasoline and its vapors are highly flammable and explosive.** Always, refuel according to the procedure on page 52 to reduce the risk of fire and explosion.

EMU33821

## Gasoline exposure and spills

Take care not to spill gasoline. If gasoline spills, wipe it up immediately with dry rags. Dispose of rags properly.

If any gasoline spills onto your skin, immediately wash with soap and water. Change clothing if gasoline spills on it.

If you swallow gasoline, inhale a lot of gasoline vapor, or get gasoline in your eyes, get immediate medical attention. Never siphon fuel by mouth.

EMU33901

## Carbon monoxide

This product emits exhaust gases which contain carbon monoxide, a colorless, odorless gas which may cause brain damage or death when inhaled. Symptoms include nausea, dizziness, and drowsiness. Keep cockpit and cabin areas well ventilated. Avoid blocking exhaust outlets.

EMU33781

## Modifications

Do not attempt to modify this outboard motor. Modifications to your outboard motor may reduce safety and reliability, and render the outboard unsafe or illegal to use.

EMU33742

## Boating safety

This section includes a few of the many important safety precautions that you should follow when boating.

EMU33711

## Alcohol and drugs

Never operate after drinking alcohol or taking drugs. Intoxication is one of the most common factors contributing to boating fatalities.

EMU40281

## Personal flotation devices (PFDs)

Have an approved PFD on board for every occupant. Yamaha recommends that you must wear a PFD whenever boating. At a minimum, children and non-swimmers should always wear PFDs, and everyone should wear PFDs when there are potentially hazardous boating conditions.

EMU33732

## People in the water

Always watch carefully for people in the water, such as swimmers, skiers, or divers, whenever the engine is running. When someone is in the water near the boat, shift into neutral and stop the engine.

Stay away from swimming areas. Swimmers can be hard to see.

The propeller can keep moving even when the motor is in neutral. Stop the engine when a person is in the water near you.

EMU33752

## Passengers

Consult your boat manufacturer's instructions for details about appropriate passenger locations in your boat and be sure all passengers are positioned properly before accelerating and when operating above an

## Safety information

idle speed. Standing or sitting in non-designated locations may result in being thrown either overboard or within the boat due to waves, wakes, or sudden changes in speed or direction. Even when people are positioned properly, alert your passengers if you must make any unusual maneuver. Always avoid jumping waves or wakes.

EMU33763


### Overloading

Do not overload the boat. Consult the boat capacity plate or boat manufacturer for maximum weight and number of passengers. Be sure that weight is properly distributed according to the boat manufacturer's instructions. Overloading or incorrect weight distribution can compromise the boat's handling and lead to an accident, capsizing or swamping.

EMU33773

### Avoid collisions

Scan constantly for people, objects, and other boats. Be alert for conditions that limit your visibility or block your vision of others.



ZMU06025

Operate defensively at safe speeds and keep a safe distance away from people, objects, and other boats.

- Do not follow directly behind other boats or waterskiers.

- Avoid sharp turns or other maneuvers that make it hard for others to avoid you or understand where you are going.
- Avoid areas with submerged objects or shallow water.
- Ride within your limits and avoid aggressive maneuvers to reduce the risk of loss of control, ejection, and collision.
- Take early action to avoid collisions. Remember, boats do not have brakes, and stopping the engine or reducing throttle can reduce the ability to steer. If you are not sure that you can stop in time before hitting an obstacle, apply throttle and turn in another direction.

EMU48100

### Collisions with floating or submerged objects


If the outboard motor hits a floating object or an obstacle in the water while cruising, the following could occur:

- The passengers and any loose equipment or luggage could be thrown forward due to the sudden deceleration.
- Parts of the outboard motor could come loose as a result of the impact and could be thrown into the boat.
- The boat or outboard motor could be damaged as a result of the impact.

When you operate the boat in an area where there might be floating objects or obstacles in the water, be sure to adjust the trim angle of the outboard motor, slow down, and operate carefully. For further information, see page 66.

If the outboard motor hits a floating object or an obstacle in the water, make sure that there are no abnormalities with the boat and the outboard motor. If anything abnormal is found, return to the nearest harbor at low

speed and have a Yamaha dealer inspect the outboard motor.



EMU33791

## **Weather**

Stay informed about the weather. Check weather forecasts before boating. Avoid boating in hazardous weather.

EMU33881

## **Passenger training**

Make sure at least one other passenger is trained to operate the boat in the event of an emergency.

EMU33891

## **Boating safety publications**

Be informed about boating safety. Additional publications and information can be obtained from many boating organizations.

EMU33602

## **Laws and regulations**

Know the marine laws and regulations where you will be boating—and obey them. Several sets of rules prevail according to geographic location, but all are basically the same as the International Rules of the Road.

# General information

EMU25172


## Identification numbers record

EMU25186

### Outboard motor serial number


The outboard motor serial number is stamped on the label attached to the port side of the clamp bracket.

Record your outboard motor serial number in the spaces provided to assist you in ordering spare parts from your Yamaha dealer or for reference in case your outboard motor is stolen.



ZMU01691

1. Outboard motor serial number location



1. Serial number
2. Model name
3. Motor transom height
4. Engine code


EMU25192

## Key number

If a main key switch is equipped with the motor, the key identification number is stamped on your key as shown in the illustration. Record this number in the space provided for reference in case you need a new key.

|  |  |  |
|--|--|--|
|  |  |  |
|--|--|--|

ZMU01693



ZMU01694

1. Key number

EMU38984

## EC Declaration of Conformity (DoC)

This declaration is included with outboard motors that conform to European regulations.

This outboard motor conforms to certain portions of the European Parliament directive relating to machinery.


Each conformed outboard motor accompanied with EC DoC. EC DoC contains the following information;

- Manufacturer
- Model name
- Engine code
- Applied directives

EMU48442

## CE Marking / UKCA Marking

This label is affixed to outboard motors that conform to European regulations.



1. CE marking location



### CE marking

Outboard motors affixed with this “CE” marking conform with the directives of; 2006/42/EC, 2014/30/EU, and 2013/53/EU.

### UKCA marking

This product is in compliance with the Recreational Craft Regulations 2017, Electromagnetic Compatibility Regulations 2016 and Supply of Machinery (Safety) Regulations 2008.

# General information

---

EMU33524

## Read manuals and labels

Before operating or working on this outboard motor:

- Read this manual.
- Read any manuals supplied with the boat.
- Read all labels on the outboard motor and the boat.


If you need any additional information, contact your Yamaha dealer.

EMU33836


## Warning labels

If these labels are damaged or missing, contact your Yamaha dealer for replacements.

**F40L, F50L, FT50N, F60H, FT60J**



F40N, F70B



# General information

1

**⚠ WARNING**

Emergency starting does not have start-in-gear protection. Ensure shift control is in neutral before starting engine.

6EE-81995-41

**⚠ AVERTISSEMENT**

Le démarrage d'urgence ne comporte pas de sécurité de démarrage embrayé. Veillez à ce que le changement de vitesses se trouve au point mort avant de faire démarrer le moteur.

6EE-81995-51



YAMAHA

6AG-81996-01

2

**⚠ WARNING**

- Keep hands, hair, and clothing away from rotating parts while the engine is running.
- Do not touch or remove electrical parts when starting or during operation.

6EE-81994-41

**⚠ AVERTISSEMENT**

- Garder les mains, les cheveux et les vêtements à l'écart des pièces en rotation lorsque le moteur tourne.
- Ne touchez et ne retirez aucune pièce électrique lors du démarrage ou de l'utilisation.

6EE-81994-51

3

**⚠ WARNING**

- Read Owner's Manuals and labels.
- Wear an approved personal flotation device (PFD).
- Attach engine shut-off cord (lanyard) to your PFD, arm, or leg so the engine stops if you accidentally leave the helm, which could prevent a runaway boat.

6EE-42794-41

**⚠ AVERTISSEMENT**

- Lire le Manuel de l'Utilisateur et les étiquettes.
- Portez un gilet de sauvetage homologué.
- Attachez le cordon d'arrêt du moteur (coupe-circuit) à votre gilet de sauvetage, à votre bras ou à votre jambe pour que le moteur s'arrête si vous quittez accidentellement la barre. Cela permet d'éviter que le bateau ne poursuive sa route sans contrôle.

6EE-42794-51

EMU33913

## Contents of labels

The above warning labels mean as follows.

1

EWM01692

**⚠ WARNING**

Emergency starting does not have start-in-gear protection. Ensure shift control is in neutral before starting engine.

2

EWM01682

**⚠ WARNING**

- Keep hands, hair, and clothing away from rotating parts while the engine is running.
- Do not touch or remove electrical parts when starting or during operation.

3

EWM01672

**⚠ WARNING**

- Read Owner's Manuals and labels.
- Wear an approved personal flotation device (PFD).
- Attach engine shut-off cord (lanyard) to your PFD, arm, or leg so the engine stops if you accidentally leave the helm, which could prevent a runaway boat.

# General information

EMU33845

## Symbols

The following symbols mean as follows.

### Notice/Warning



ZMU05696

### Read Owner's Manual



ZMU05664

### Hazard caused by continuous rotation



ZMU05665

### Electrical hazard




ZMU05666

### Remote control lever/gear shift lever operating direction, dual direction



ZMU05667

### Engine start/ Engine cranking



ZMU05668

# General information

---

EMU49582

## Use of your data

**This is a brief summary of how Yamaha (Yamaha Motor Co., Ltd., and Yamaha Motor Europe N.V.) uses your data. For more details, please go to the specific URL below for the Privacy Policy:**

Austria (German)

<https://www.yamaha-motor.eu/at/de/privacy/privacy-policy/>

Belgium (Dutch)

<https://www.yamaha-motor.eu/be/nl/privacy/privacy-policy/>

Belgium (French)

<https://www.yamaha-motor.eu/be/fr/privacy/privacy-policy/>

Bulgaria (Bulgarian)

<https://www.yamaha-motor.eu/bg/bg/privacy/privacy-policy/>

Czech Republic (Czech)

<https://www.yamaha-motor.eu/cz/cs/privacy/privacy-policy/>

Denmark (Danish)

<https://www.yamaha-motor.eu/dk/da/privacy/privacy-policy/>

Finland (Finnish)

<https://www.yamaha-motor.eu/fi/fi/privacy/privacy-policy/>

France (French)

<https://www.yamaha-motor.eu/fr/fr/privacy/privacy-policy/>

Germany (German)

<https://www.yamaha-motor.eu/de/de/privacy/privacy-policy/>

Greece (Greek)

<https://www.yamaha-motor.eu/gr/el/privacy/privacy-policy/>

Hungary (Hungarian)

<https://www.yamaha-motor.eu/hu/hu/privacy/privacy-policy/>

Italy (Italian)

<https://www.yamaha-motor.eu/it/it/privacy/privacy-policy/>

Ireland (English)

<https://www.yamaha-motor.eu/ie/en/privacy/privacy-policy/>

Netherlands (Dutch)

<https://www.yamaha-motor.eu/nl/nl/privacy/Privacybeleid/>

Norway (Norwegian)

<https://www.yamaha-motor.eu/no/nb/privacy/privacy-policy/>

Poland (Polish)

<https://www.yamaha-motor.eu/pl/pl/privacy/polityka-prywatnosci/>

Portugal (Portuguese)

<https://www.yamaha-motor.eu/pt/pt/privacy/privacy-policy/>

Romania (Romanian)

<https://www.yamaha-motor.eu/ro/ro/privacy/privacy-policy/>

Spain (Spanish)

<https://www.yamaha-motor.eu/es/es/privacy/privacy-policy/>

Sweden (Swedish)

<https://www.yamaha-motor.eu/se/sv/privacy/privacy-policy/>

Switzerland (German)

<https://www.yamaha-motor.eu/ch/de/privacy/privacy-policy/>

Switzerland (French)

<https://www.yamaha-motor.eu/ch/fr/privacy/privacy-policy/>

Turkey (Turkish)

<https://www.yamaha-motor.eu/tr/tr/privacy/privacy-policy/>

U.K. (English)

<https://www.yamaha-motor.eu/gb/en/privacy/privacy-policy/>

## **What data we collect? and How we collect your data?**

This outboard motor collects three types of data through integrated Engine Control Units (ECU): (1) Outboard motor serial number; (2) live data showing the performance of the outboard motor such as engine/motor operating state, boat speed, mileage; and (3) other data showing the status of the outboard motor such as diagnostic trouble code (DTC).

The collected data will be uploaded to server at Yamaha Motor Co., Ltd. by attaching a special Yamaha diagnostic tool to the outboard motor, only when maintenance checks or service procedures are performed.

## **How will we use your data?**

Yamaha use collected data from your outboard motor, (1) to conduct adequate maintenance service including diagnostics, (2) to implement proper warranty claim judgement, (3) to conduct research and development of outboard motor, (4) to provide and improve quality of products, features, and services, (5) to ensure our business purpose, and (6) to comply with requirements of laws and regulations.

## **How we share your data?**

We may share your data with: (i) our subsidiaries, affiliates, and business partners; (ii) dealers in your country or region, and (iii) contractors within the scope necessary to achieve the purpose of use described above.

## **How to contact us**

Yamaha Motor Co., Ltd., and Yamaha Motor Europe N.V. are joint data controller regarding your data collected. Any questions or complaints regarding the processing of your Personal Data can be submitted in writing to:

**Yamaha Motor Europe N.V./Digital Marketing & CRM**

**– PO Box 75033 – 1117 ZN Schiphol – The Netherlands.**

**The SOLE PURPOSE of above provided contact information is TO RESPOND DATA PROCESSING INQUIRY AND OTHER KINDS OF INQUIRIES WILL NOT BE RESPONDED.**

Please provide the following information for the proper handling of your inquiry: **(1) Your Name; (2) Your Email Address; (3) Your Country of Residence; and (4) Your outboard**

# General information

---

**motor serial number.** We will use your personal information provided only for the purpose of supporting your data processing inquiry.

# Specifications and requirements

EMU38092

## Specifications

### TIP:

“(AL)” stated in the specification data below represents the numerical value for the aluminum propeller installed.

EMU48364

### Dimension and weight:

Overall length:

713 mm (28.1 in) (F40NET, F70BET)

714 mm (28.1 in) (F40LET, F50LED,  
F50LET, F60HET, FT50NET,  
FT60JET)

Overall width:

384 mm (15.1 in) (F40LET, F50LED,  
F50LET, F60HET, FT50NET,  
FT60JET)

386 mm (15.2 in) (F40NET, F70BET)

Overall height L:

1439 mm (56.7 in) (F40LET, F50LED,  
F50LET, F60HET)

1479 mm (58.2 in) (FT50NET,  
FT60JET)

1484 mm (58.4 in) (F40NET, F70BET)

Overall height X:

1593 mm (62.7 in) (FT60JET)

1598 mm (62.9 in) (F70BET)

Motor transom height L:

527 mm (20.7 in) (F40LET, F50LED,  
F50LET, F60HET)

530 mm (20.9 in) (FT50NET,  
FT60JET)

534 mm (21.0 in) (F40NET, F70BET)

Motor transom height X:

644 mm (25.4 in) (FT60JET)

648 mm (25.5 in) (F70BET)

Dry weight (AL) L:

111 kg (245 lb) (F50LED)

114 kg (251 lb) (F40LET, F50LET,

F60HET)

119 kg (262 lb) (FT50NET, FT60JET)

120 kg (265 lb) (F40NET, F70BET)

Dry weight (AL) X:

123 kg (271 lb) (FT60JET)

124 kg (273 lb) (F70BET)

### Performance:

Full throttle operating range:

5000–6000 r/min (F40LET, F50LED,  
F50LET, F60HET, FT50NET,  
FT60JET)

5300–6300 r/min (F40NET, F70BET)

Rated power:

29.4 kW (40 HP) (F40LET, F40NET)

36.8 kW (50 HP) (F50LED, F50LET,  
FT50NET)

44.1 kW (60 HP) (F60HET, FT60JET)

51.5 kW (70 HP) (F70BET)

Idle speed (in neutral):

700–800 r/min

### Power unit:

Type:

4-stroke SOHC L4 16 valves  
(F40NET, F70BET)

4-stroke SOHC L4 8 valves (F40LET,  
F50LED, F50LET, F60HET,  
FT50NET, FT60JET)

Total displacement:

996 cm<sup>3</sup> (60.8 c.i.)

Bore × stroke:

65.0 × 75.0 mm (2.56 × 2.95 in)

Ignition system:

TCI

Spark plug (NGK):

DPR6EB-9 (F40LET, F50LED,  
F50LET, F60HET, FT50NET,  
FT60JET)

LKR7E (F40NET, F70BET)

Spark plug gap:

0.8–0.9 mm (0.031–0.035 in)

# Specifications and requirements

---

## Steering system:

Remote steering

## Starting system:

Electric starter

## Starting carburetion system:

Fuel injection

## Valve clearance IN (cold engine):

0.15–0.25 mm (0.0059–0.0098 in)

## Valve clearance EX (cold engine):

0.25–0.35 mm (0.0098–0.0138 in)

## Battery rating (CCA/EN):

430–1080 A

## Battery rating (20HR/IEC):

70 Ah

## Maximum generator output:

15 A (F40NET, F70BET)

16 A (F40LET, F50LED, F50LET,

F60HET, FT50NET, FT60JET)

## Lower unit:

### Gear shift positions:

Forward-neutral-reverse

### Gear ratio:

1.85 (24/13) (F40LET, F50LED,  
F50LET, F60HET)

2.33 (28/12) (F40NET, F70BET,  
FT50NET, FT60JET)

### Trim and tilt system:

Hydro tilt (F50LED)

Power trim and tilt (F40LET, F40NET,  
F50LET, F60HET, F70BET,  
FT50NET, FT60JET)

### Propeller mark:

G (F40LET, F50LED, F50LET,  
F60HET)

K (F40NET, F70BET, FT50NET,  
FT60JET)

## Fuel and oil:

### Recommended fuel:

Regular unleaded gasoline

### Min. research octane number (RON):

90

## Fuel tank capacity:

24 L (6.34 US gal, 5.28 Imp.gal)

## Recommended engine oil:

YAMALUBE 4 or 4-stroke outboard  
motor oil



## Recommended engine oil grade 1:

SAE 10W-30/10W-40/5W-30

API SE/SF/SG/SH/SJ/SL

## Engine oil quantity (without oil filter replacement):

1.9 L (2.01 US qt, 1.67 Imp.qt)

## Engine oil quantity (with oil filter replacement):

2.1 L (2.22 US qt, 1.85 Imp.qt)

## Lubrication system:

Wet sump

## Recommended gear oil:

YAMALUBE outboard gear oil or Hypoid gear oil

## Recommended gear oil grade:

SAE 90 API GL-4

## Gear oil quantity:

0.430 L (0.455 US qt, 0.378 Imp.qt)  
(F40LET, F50LED, F50LET, F60HET)

0.670 L (0.708 US qt, 0.590 Imp.qt)  
(F40NET, F70BET, FT50NET,  
FT60JET)

## Noise and vibration level:

### Operator sound pressure level (ICOMIA 39/94):

82.8 dB(A) (F40LET, F50LED,  
F50LET, F60HET, FT50NET,  
FT60JET)

80.9 dB(A) (F40NET, F70BET)

# Specifications and requirements

EMU33556

## Installation requirements

EMU33566

### Boat horsepower rating

EWM01561



#### WARNING

**Overpowering a boat can cause severe instability.**

Before installing the outboard motor(s), confirm that the total horsepower of your outboard motor(s) does not exceed the boat's maximum horsepower rating. See the boat's capacity plate or contact the manufacturer.

EMU40491

### Mounting outboard motor

EWM02501



#### WARNING

- **Improper mounting of the outboard motor could result in hazardous conditions such as poor handling, loss of control, or fire hazards.**
- **Because the outboard motor is very heavy, special equipment and training is required to mount it safely.**

Your dealer or other person experienced in proper rigging should mount the outboard motor using correct equipment and complete rigging instructions. For further information, see page 44.

EMU33582

## Remote control requirements

EWM01581



#### WARNING

- **If the engine starts in gear, the boat can move suddenly and unexpectedly, possibly causing a collision or throwing passengers overboard.**
- **If the engine ever starts in gear, the start-in-gear protection device is not**

**working correctly and you should discontinue using the outboard. Contact your Yamaha dealer.**

The remote control unit must be equipped with a start-in-gear protection device(s). This device prevents the engine from starting unless it is in neutral.

EMU25695

## Battery requirements

EMU25723

### Battery specifications

**Battery rating (CCA/EN):**

430–1080 A

**Battery rating (20HR/IEC):**

70 Ah

The engine cannot be started if battery voltage is too low.

EMU36293

### Mounting battery

Mount the battery holder securely in a dry, well-ventilated, vibration-free location in the boat. **WARNING! Do not put flammable items, or loose heavy or metal objects in the same compartment as the battery. Fire, explosion or sparks could result.**

[EWM01821]

### Battery cable

The battery cable size and length are critical. Consult your Yamaha dealer about the battery cable size and length.

EMU41604

## Propeller selection

Next to selecting an outboard motor, selecting the right propeller is one of the most important purchasing decisions a boater can


# Specifications and requirements

make. The type, size, and design of your propeller have a direct impact on acceleration, top speed, fuel economy, and even engine life. Yamaha designs and manufactures propellers for every Yamaha outboard motor and every application.

Your Yamaha dealer can help you select the right propeller for your boating needs. Select a propeller that will allow the engine to reach the middle or upper half of the operating range at full throttle with the maximum boat-load. Generally, select a larger pitch propeller for a smaller operating load and a smaller pitch propeller for a heavier load. If you carry loads that vary widely, select the propeller that lets the engine run in the proper range for your maximum load but remember that you may need to reduce your throttle setting to stay within the recommended engine speed range when carrying lighter loads. Yamaha recommends to use a propeller suitable for the "Shift Dampener System (SDS)". For further information, consult your Yamaha dealer.


To check the propeller, see page 85.

## Propeller example




ZMU04606

1. Propeller diameter in inches
2. Propeller pitch in inches
3. Type of propeller (propeller mark)



ZMU04607

1. Propeller diameter in inches
2. Propeller pitch in inches
3. Type of propeller (propeller mark)



ZMU05937

1. Propeller pitch in inches
2. Type of propeller (propeller mark)
3. Propeller diameter in inches

EMU25771

## Start-in-gear protection

Yamaha outboard motors or Yamaha-approved remote control units are equipped with start-in-gear protection device(s). This feature permits the engine to be started only when it is in neutral. Always select neutral before starting the engine.

# Specifications and requirements

EMU41953

## Engine oil requirements

Select an oil grade according to the average temperatures in the area where the outboard motor will be used.

### Recommended engine oil:

YAMALUBE 4 or 4-stroke outboard motor oil

### Recommended engine oil grade 1:

SAE 10W-30/10W-40/5W-30

API SE/SF/SG/SH/SJ/SL

### Recommended engine oil grade 2:

SAE 15W-40/20W-40/20W-50

API SH/SJ/SL

### Engine oil quantity (without oil filter replacement):


1.9 L (2.01 US qt, 1.67 Imp.qt)

### Engine oil quantity (with oil filter replacement):

2.1 L (2.22 US qt, 1.85 Imp.qt)


If oil grades listed under Recommended engine oil grade 1 are not available, select an alternative oil grade listed under Recommended engine oil grade 2.

### Recommended engine oil grade 1



ZMU06854

## Recommended engine oil grade 2



ZMU06855

EMU36361

## Fuel requirements

EMU40203

### Gasoline

Use a good quality gasoline that meets the minimum octane rating. If knocking or pinging occurs, use a different brand of gasoline or premium unleaded fuel.

### Recommended fuel:

Regular unleaded gasoline

**Min. research octane number (RON):**  
90

ECM01982

### NOTICE

- Do not use leaded gasoline. Leaded gasoline can seriously damage the engine.
- Avoid getting water and contaminants in the fuel tank. Contaminated fuel can cause poor performance or engine damage. Use only fresh gasoline that has been stored in clean containers.

# Specifications and requirements



## TIP:

- This mark identifies the recommended fuel for this outboard motor as specified by European regulation (EN228).
- Check that gasoline nozzle has the same identifier when fueling.

## Gasohol

There are two types of gasohol: gasohol containing ethanol (E5 and E10) and that containing methanol. Ethanol can be used if the ethanol content does not exceed 10% and the fuel meets the minimum octane ratings. E85 is a fuel containing 85% ethanol and must not be used in your outboard motor. All ethanol blends containing more than 10% ethanol can cause fuel system damage or cause engine starting and running problems. Yamaha does not recommend gasohol containing methanol because it can cause fuel system damage or engine performance problems.

It is recommended that you install a water-separating marine fuel filter assembly (10 micron minimum) between your boat's fuel tank and outboard motor when using ethanol. Ethanol is known to allow moisture to be absorbed into boat fuel tanks and systems. Moisture in the fuel can cause corrosion of metallic fuel system components, starting and running complaints and require additional fuel system maintenance.

EMU36881

## Muddy or acidic water


Yamaha strongly recommends that you have your dealer install the optional chromium-plated water pump kit if you use the outboard motor in muddy or acidic water conditions. However, depending on the model it might not be required.

EMU36331

## Anti-fouling paint

A clean hull improves boat performance. The boat bottom should be kept as clean of marine growth as possible. If necessary, the boat bottom can be coated with an anti-fouling paint approved for your area to inhibit marine growth.

Do not use anti-fouling paint which includes copper or graphite. These paints can cause more rapid engine corrosion.



ZMU05176

EMU40302

## Outboard motor disposal requirements

Never illegally discard (dump) the outboard motor. Yamaha recommends consulting the dealer about discarding the outboard motor.

EMU36353

## **Emergency equipment**

Keep the following items onboard in case there is trouble with the outboard motor.

- A tool kit with assorted screwdrivers, pliers, wrenches (including metric sizes), and electrical tape.
- Waterproof flashlight with extra batteries.
- An extra engine shut-off cord (lanyard) with clip.
- Spare parts, such as an extra set of spark plugs.

Consult your Yamaha dealer for details.

# Components


EMU46722

## Components diagram

### TIP:

\* May not be exactly as shown; also may not be included as standard equipment on all models (order from dealer).


**F40L, F50L, FT50N, F60H, FT60J**



1. Top cowling
2. Water separator
3. Cowling lock lever
4. Drain screw
5. Anode\*
6. Anti-cavitation plate
7. Trim tab (anode)
8. Propeller\*
9. Cooling water inlet
10. Anode(s)\*
11. Trim rod\*
12. Tilt lock lever\*
13. Clamp bracket
14. Tilt support lever

15. Power trim and tilt switch\*
16. Flushing device
17. Fuel tank\*

## F40N, F70B




1. Top cowling
2. Water separator
3. Cowling lock lever
4. Drain screw
5. Anti-cavitation plate
6. Trim tab (anode)
7. Propeller\*
8. Cooling water inlet
9. Anode(s)
10. Clamp bracket
11. Tilt support lever
12. Power trim and tilt switch
13. Flushing device
14. Fuel tank\*

# Components

EMU46733

## Optional items

The following items are available from your Yamaha dealer. For details, consult your Yamaha dealer.



ZMU08550

1. Tiller handle
2. Remote control box (side mount type)
3. Digital tachometer
4. Digital speedometer
5. 6Y8 Multifunction tachometer
6. 6Y8 Multifunction speed & fuel meter
7. Yamaha Security System (Y-COP)

EMU25804

## Fuel tank


If your model was equipped with a portable fuel tank, its function is as follows.

EWM00021



**WARNING**

The fuel tank supplied with this engine is its dedicated fuel reservoir and must not be used as a fuel storage container. Commercial users should conform to relevant licensing or approval authority regulations.



1. Fuel joint
2. Fuel gauge
3. Fuel tank cap
4. Air vent screw

EMU25831

## Fuel joint

This joint is used to connect the fuel line.

EMU25842

## Fuel gauge

This gauge is located on either the fuel tank cap or on the fuel joint base. It shows the approximate amount of fuel remaining in the tank.

EMU25851

## Fuel tank cap

This cap seals the fuel tank. When removed, the tank can be filled with fuel. To remove the cap, turn it counterclockwise.

EMU25861

## Air vent screw

This screw is on the fuel tank cap. To loosen the screw, turn it counterclockwise.

EMU46753


## Yamaha Security System (Y-COP/Optional)

ECM02461

### NOTICE

The Yamaha Security System is sold in conformity with the relevant laws and regulations regarding radio wave transmission. Therefore, if this product is used outside the country where it was sold, it may violate the laws or regulations regarding radio wave transmission in the country it is used in. For details, consult your Yamaha dealer.

The Yamaha Security System, which protects against theft, consists of the receiver and key fobs. The Yamaha Security System is available from your Yamaha dealer. For details, consult your Yamaha dealer.



1. Key fob
2. Receiver


# Components

The engine cannot be started if the security system is in the lock mode. The engine can be started only in the unlock mode. For more information, see the installation and owner's manual included with the security system.

EMU26183

## Remote control box

The remote control lever actuates both the shifter and the throttle. The electrical switches are mounted on the remote control box.




1. Power trim and tilt switch
2. Remote control lever
3. Neutral interlock trigger
4. Neutral throttle lever
5. Main switch
6. Engine shut-off switch
7. Throttle friction adjuster

EMU26192

## Remote control lever

Moving the lever forward from the neutral position engages forward gear. Pulling the lever back from neutral engages reverse. The engine will continue to run at idle until the lever is moved about 35° (a detent can be felt). Moving the lever farther opens the throttle, and the engine will begin to accelerate.




1. Neutral "N"
2. Forward "F"
3. Reverse "R"
4. Shift
5. Fully closed
6. Throttle
7. Fully open

EMU26202

## Neutral interlock trigger

To shift out of neutral, first pull the neutral interlock trigger up.




1. Neutral interlock trigger

EMU26213

## Neutral throttle lever

To open the throttle without shifting into either forward or reverse, put the remote control lever in the neutral position and lift the neutral throttle lever.



1. Fully open
2. Fully closed


## TIP:

The neutral throttle lever will operate only when the remote control lever is in neutral. The remote control lever will operate only when the neutral throttle lever is in the closed position.

EMU25914

## Tiller handle


To change direction, move the tiller handle to the left or right as necessary.



EMU25925

## Gear shift lever

Move the gear shift lever forward to engage the forward gear or rearward to engage the reverse gear.




1. Forward "F"
2. Neutral "N"
3. Reverse "R"

EMU25943

## Throttle grip

The throttle grip is on the tiller handle. Turn the grip counterclockwise to increase speed and clockwise to decrease speed.




EMU25963

## Throttle indicator

The fuel consumption curve on the throttle indicator shows the relative amount of fuel consumed for each throttle position. Choose the setting that offers the best performance and fuel economy for the desired operation.

# Components



ZMU05206


## 1. Throttle indicator

EMU25978


### Throttle friction adjuster

A friction device provides adjustable resistance to movement of the throttle grip or the remote control lever, and can be set according to operator preference.

To increase resistance, turn the adjuster clockwise. To decrease resistance, turn the adjuster counterclockwise. **WARNING! Do not overtighten the friction adjuster. If there is too much resistance, it could be difficult to move the remote control lever or throttle grip, which could result in an accident.** [EWM00033]



ZMU01714




ZMU05207

When constant speed is desired, tighten the adjuster to maintain the desired throttle setting.

EMU25996


### Engine shut-off cord (lanyard) and clip

The clip must be attached to the engine shut-off switch for the engine to run. The cord should be attached to a secure place on the operator's clothing, or arm or leg. Should the operator fall overboard or leave the helm, the cord will pull out the clip, stopping ignition to the engine. This will prevent the boat from running away under power. **WARNING! Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg while operating. Do not attach the cord to clothing that could tear loose. Do not route the cord where it could become entangled, preventing it from functioning. Avoid accidentally pulling the cord during normal operation. Loss of engine power means the loss of most steering control. Also, without engine power, the boat could slow rapidly. This could cause people and objects in the boat to be thrown forward.** [EWM00123]



ZMU01716

1. Engine shut-off cord (lanyard)
2. Clip
3. Engine shut-off switch




ZMU05208

1. Engine shut-off cord (lanyard)
2. Clip
3. Engine shut-off switch

EMU26004

## Engine stop button

The engine stop button stops the engine when the button is pushed.



ZMU05209

EMU26092

## Main switch

The main switch controls the ignition system; its operation is described below.

### ● "OFF" (off)


With the main switch in the "OFF" (off) position, the electrical circuits are off, and the key can be removed.

### ● "ON" (on)

With the main switch in the "ON" (on) position, the electrical circuits are on, and the key cannot be removed.


### ● "START" (start)

With the main switch in the "START" (start) position, the starter motor turns to start the engine. When the key is released, it returns automatically to the "ON" (on) position.



ZMU01718

# Components



EMU31433

## Steering friction adjuster

A friction device provides adjustable resistance to the steering mechanism, and can be set according to operator preference. An adjuster lever is located on the bottom of the tiller handle bracket.

To increase resistance, turn the lever to the port side “A”.


To decrease resistance, turn the lever to the starboard side “B”.

EWM00041




### WARNING

**Do not overtighten the friction adjuster. If there is too much resistance, it could be difficult to steer, which could result in an accident.**



If the resistance does not increase even when the lever is turned to the port side “A”,

make sure that the nut is tightened to the specified torque.



1. Nut

### Nut tightening torque:

6 N·m (0.6 kgf·m, 4.4 lb·ft)

### TIP:


- Steering movement is blocked when the adjuster lever is set to the “A” position.
- Check the tiller handle for smooth movement when the lever is turned to the starboard side “B”.
- Do not apply lubricants such as grease to the friction areas of the steering friction adjuster.

EMU26144


## Power trim and tilt switch on remote control or tiller handle

The power trim and tilt system adjusts the outboard motor angle in relation to the transom. Pressing the switch “UP” (up) trims the outboard motor up, and then tilts it up. Pressing the switch “DN” (down) tilts the outboard motor down and trims it down. When the switch is released, the outboard motor will stop in its current position.

For instructions on using the power trim and tilt switch, see pages 59 and 62.



ZMU01720



ZMU05211

EMU26156

## Power trim and tilt switch on bottom cowling

The power trim and tilt switch is located on the side of the bottom cowling. Pushing the switch “UP” (up) trims the outboard motor up, and then tilts it up. Pushing the switch “DN” (down) tilts the outboard motor down and trims it down. When the switch is released, the outboard motor will stop in its current position.

For instructions on using the power trim and tilt switch, see page 62.


EWMO1032



**WARNING**

**Use the power trim and tilt switch located on the bottom cowling only when the boat is at a complete stop with the engine off. Attempting to use this switch while the boat is moving could increase the risk of**

**falling overboard and could distract the operator, increasing the risk of collision with another boat or an obstacle.**




ZMU07913

### 1. Power trim and tilt switch

EMU30903

## Variable trolling RPM switches

The trolling speed can be adjusted when the outboard motor is trolling. Press the “UP” switch to increase the trolling speed and press the “DN” switch to decrease the trolling speed.



ZMU05213

### 1. Variable trolling RPM switch

## TIP:

- The trolling speed changes approximately 50 r/min each time a switch is pressed.
- If the trolling speed has been adjusted, the engine returns to the normal trolling speed when the engine is stopped and restarted

# Components

or when the engine speed exceeds approximately 3000 r/min.

- For instructions on using the variable trolling RPM switches, see page 58.

EMU26246

## Trim tab with anode

EWM00841

### WARNING

An improperly adjusted trim tab could cause difficult steering. Always test run after the trim tab has been installed or replaced to be sure steering is correct. Be sure you have tightened the bolt after adjusting the trim tab.


The trim tab should be adjusted so that the steering control can be turned to either the right or left by applying the same amount of force.

If the boat tends to veer to the left (port side), turn the trim tab rear end to the port side “A” in the figure. If the boat tends to veer to the right (starboard side), turn the trim tab end to the starboard side “B” in the figure.

ECM00841

### NOTICE

The trim tab also serves as an anode to protect the engine from electrochemical corrosion. Never paint the trim tab as it will become ineffective as an anode.




ZMU02525

1. Trim tab

2. Bolt

3. Cap



ZMU03097

1. Trim tab

2. Bolt

### Bolt tightening torque:

18 N·m (1.8 kgf·m, 13 lb·ft)

(F40L, F50L, F60H)


37 N·m (3.7 kgf·m, 27 lb·ft)

(F40N, FT50N, FT60J, F70B)

EMU26263

## Trim rod (tilt pin)

The position of the trim rod determines the minimum trim angle of the outboard motor in relation to the transom.




ZMU03593

EMU26314

## Tilt lock mechanism

The tilt lock mechanism is used to prevent the outboard motor from lifting out of the water when in reverse gear.



1. Tilt lock lever


To lock it, set the tilt lock lever in the “” (lock) position.

To release, push the tilt lock lever in the “” (release) position.

EMU34462

## Tilt support lever for power trim and tilt or hydro tilt model

To keep the outboard motor in the tilted up position, lock the tilt support lever to the clamp bracket.



ECM00661


## NOTICE

**Do not use the tilt support lever or knob when trailering the boat. The outboard motor could shake loose from the tilt support and fall. If the motor cannot be trailered in the normal running position, use an additional support device to secure it in the tilt position.**

EMU40762

## Cowling lock lever

The cowling lock levers are used to secure the top cowling.




1. Cowling lock lever(s)

EMU26464

## Flushing device

This device is used to clean the cooling water passages of the motor using a garden hose and tap water.

# Components



1. Flushing device



## TIP:

For details on usage, see page 72.

EMU35564

## Fuel filter/Water separator

This engine has a combination fuel filter/water separator and associated alert system. If water separated from the fuel exceeds a specific volume, the alert device of 6Y8 Multifunction Tachometer will activate.




## Activation of alert device

- The water separator-alert indicator of 6Y8 Multifunction Tachometer will blink.
- The buzzer will sound intermittently only when the gear shift is in neutral.
- If the alert system has activated, stop the engine and consult a Yamaha dealer immediately.

EMU26305

## Alert indicator

If the engine develops a condition which is cause for alert, the indicator lights up. For details on how to read the alert indicator, see page 42.



1. Alert indicator

EMU36016

## Indicators

EMU36026


### Low oil pressure-alert indicator

If oil pressure drops too low, this indicator will light up. For further information, see page 42.

ECM00024

#### NOTICE

- Do not continue to run the engine if the low oil pressure-alert indicator is on and the engine oil level is lower. Serious engine damage will occur.
- The low oil pressure-alert indicator does not indicate the engine oil level. Use the oil dipstick to check the oil level. For further information, see page 48.



ZMU06154

1. Low oil pressure-alert indicator

EMU36034


### Overheat-alert indicator

If the engine temperature rises too high, this indicator will light up. For further information on reading the indicator, see page 42.

ECM00053

#### NOTICE

Do not continue to run the engine if the overheat-alert indicator is on. Serious engine damage will occur.




ZMU06155

1. Overheat-alert indicator

EMU26494

## Digital tachometer

The tachometer shows the engine speed and has the following functions. All segments of the display will light momentarily after the main switch is turned on and will return to normal thereafter.



ZMU03601

1. Tachometer
2. Trim meter
3. Hour meter
4. Low oil pressure-alert indicator
5. Overheat-alert indicator
6. Set button
7. Mode button

### TIP:

The water separator and engine trouble-alert indicators only operate when the engine is equipped with the appropriate functions.

# Instruments and indicators

EMU36051

## Tachometer


The tachometer displays engine speed in hundreds of revolutions per minute (r/min). For example, if the tachometer display reads “22” then the engine speed is 2200 r/min.

EMU26622

## Trim meter

This meter shows the trim angle of your out-board motor.


- Memorize the trim angles that work best for your boat under different conditions. Adjust the trim angle to the desired using the power trim and tilt switch.
- If the trim angle of your motor exceeds the trim operating range, the top segment on the trim meter display will blink.



EMU26652

## Hour meter

This meter shows the number of hours the engine has been run. It can be set to show the total number of hours or the number of hours for the current trip. The display can also be turned on and off.



To change the display format, press the “mode” (mode) button. The display can show total hours or trip hours, or turn off.

To reset the trip hours, simultaneously press the “set” (set) and “mode” (mode) buttons for more than 1 second while the trip hours are displayed. This resets the trip counter to 0 (zero).

The total number of hours the engine has been run cannot be reset.

EMU26526

## Low oil pressure-alert indicator


If oil pressure drops too low, the alert indicator will start to blink. For further information, see page 42.

ECM00024

### NOTICE

- Do not continue to run the engine if the low oil pressure-alert indicator is on and the engine oil level is lower. Serious engine damage will occur.
- The low oil pressure-alert indicator does not indicate the engine oil level. Use the oil dipstick to check the oil level. For further information, see page 48.

# Instruments and indicators



1. Low oil pressure-alert indicator

EMU26584


## Overheat-alert indicator

If the engine temperature rises too high, the alert indicator will start to blink. For further information on reading the indicator, see page 42.

ECM00053

### NOTICE

**Do not continue to run the engine if the overheat-alert indicator is on. Serious engine damage will occur.**




1. Overheat-alert indicator

EMU26603

## Digital speedometer

This gauge shows the boat speed and other information.



1. Speedometer
2. Fuel gauge
3. Trip meter/clock/voltmeter
4. Alert indicator(s)


ZMU01738

All segments of the display will light momentarily after the main switch is turned on and will return to normal thereafter.

EMU36062

## Speedometer

The speedometer displays km/h, mph, or knots, according to operator preference. Select the desired units of measurement by setting the selector switch on the back of the gauge. See the illustration for settings.



ZMU07001


1. Cap
2. Selector switch (for speed unit)
3. Selector switch (for fuel sensor)

# Instruments and indicators

EMU26714

## Fuel gauge

Eight segments indicate the fuel level. When all segments are showing, the fuel tank is full.



The fuel level reading can be inaccurate due to the position of the sensor in the fuel tank and the attitude of the boat in the water. Operation with bow-up trim or continuous turning can give false readings.

Do not adjust the selector switch for fuel sensor. Incorrectly setting the selector switch on the gauge will give false readings. Consult your Yamaha dealer on how to correctly set the selector switch. **NOTICE: Running out of fuel can damage the engine.**

[ECM01771]

EMU36072

## Trip meter / Clock / Voltmeter

The display shows either the trip meter, the clock, or the voltmeter.

To change the display, press the "mode" (mode) button repeatedly until the indicator on the face of the gauge points to "TRIP" (trip meter), "TIME" (clock), or "BATT" (voltmeter).


EMU26692

### Trip meter

This gauge displays the distance the boat has traveled since the gauge was last reset. The trip distance is shown in kilometers or miles depending upon the unit of measurement selected for the speedometer.

To reset the trip meter to zero, press the "set" (set) and "mode" (mode) buttons at the same time.

The trip distance is kept in memory by battery power. The stored data will be lost if the battery is disconnected.




ZMU01743

EMU26702

### Clock

To set the clock:

- (1) Be sure the gauge is in the "TIME" (time) mode.
- (2) Press the "set" (set) button; the hour display will begin blinking.
- (3) Press the "mode" (mode) button until the desired hour is displayed.
- (4) Press the "set" (set) button again, the minute display will begin blinking.
- (5) Press the "mode" (mode) button until the desired minute is displayed.
- (6) Press the "set" (set) button again to start the clock.



ZMU01744

# Instruments and indicators

The clock operates on battery power. Disconnecting the battery will stop the clock. Reset the clock after connecting the battery.

EMU36081

## Voltmeter

The voltmeter displays the charge of the battery in volts(V).


EMU26723

## Fuel level-alert indicator

If the fuel level decreases to one segment, the fuel level alert segment will blink.

Do not continue to operate the engine at full throttle if an alert device has activated. Get back to the port using trolling engine speed.

**NOTICE: Running out of fuel can damage the engine.** [ECM01771]



ZMU01746


1. Fuel level-alert segment

EMU26733

## Low battery voltage-alert indicator

If battery voltage drops, the display will automatically turn on and blink.

Get back to the port soon if an alert device has activated. For charging the battery, consult your Yamaha dealer.



ZMU01747

1. Low battery indicator


EMU46654

## 6Y8 Multifunction meters

There are two types of 6Y8 Multifunction meters.

- 6Y8 Multifunction tachometer
- 6Y8 Multifunction speed & fuel meter


### 6Y8 Multifunction tachometer



ZMU08407

1. Set button
2. Mode button


# Instruments and indicators



ZMU08408


- 1. Tachometer
- 2. Trim meter
- 3. Multifunction display

## 6Y8 Multifunction speed & fuel meter



ZMU08409

- 1. Set button
- 2. Mode button



ZMU08410


- 1. Speedometer
- 2. Fuel meter
- 3. Multifunction display

## TIP:

The information displayed on the multifunction display can be changed. For information on other settings or changing the displayed information, see the operation manual included with the 6Y8 Multifunction meter.

This manual mainly covers the alert display of the 6Y8 Multifunction tachometer. See the following sections for information about the alert indicators.

## Indicators



ZMU08411


- 1. Yamaha Security System indicator (optional)
- 2. Water separator-alert indicator
- 3. Engine trouble-alert indicator
- 4. Battery voltage indicator
- 5. Overheat-alert indicator
- 6. Low oil pressure-alert indicator
- 7. Cooling water pressure indicator (optional)

## Yamaha Security System indicator (optional)

This indicator appears, when the Yamaha Security System is in lock mode.

# Instruments and indicators

## Lock mode




1. Yamaha Security System indicator (optional)

Make sure that the Yamaha Security System indicator is off before starting the engine.

## Water separator-alert indicator

If water has accumulated in the water separator (fuel filter) while cruising, the water separator-alert indicator will start to blink.



1. Water separator-alert indicator

Stop the engine immediately and see page 94 of this manual to drain the water from the fuel filter. Get back to the port soon and consult a Yamaha dealer immediately.


ECM00911

## NOTICE

**Gasoline mixed with water could cause damage to the engine.**

## Engine trouble-alert indicator

If the engine malfunctions while cruising, the engine trouble-alert indicator will start to blink. Get back to the port soon and consult a Yamaha dealer immediately.



1. Engine trouble-alert indicator


ECM00921

## NOTICE

**In such an event, the engine will not operate properly. Consult a Yamaha dealer immediately.**

## Low battery voltage alert

If the battery voltage drops, the battery voltage value will start to blink.




1. Battery voltage value

Get back to the port soon if the low battery voltage alert device has activated. For charging the battery, consult your Yamaha dealer.

# Instruments and indicators

## Overheat-alert indicator

If the engine temperature rises too high while cruising, the overheat-alert indicator will start to blink, and the engine speed will automatically decrease to about 2000–3500 r/min.



1. Overheat-alert indicator

Stop the engine immediately if the buzzer sounds and the overheat device has activated. Check the cooling water inlet for clogging.


ECM01594

### NOTICE

- Do not continue to run the engine if the overheat-alert indicator blinks. Serious engine damage will occur.
- Do not continue to operate the engine if an alert device has activated. Consult your Yamaha dealer if the problem cannot be located and corrected.

## Low oil pressure-alert indicator

If the engine oil pressure drops too low, the low oil pressure-alert indicator will start to blink, and the engine speed will automatically decrease to about 2000–3500 r/min.



1. Low oil pressure-alert indicator

Stop the engine immediately if the buzzer sounds and the low oil pressure-alert indicator blinks. Check the engine oil level and replenish oil if necessary. If the alert device has activated while the appropriate engine oil level is maintained, consult your Yamaha dealer.

ECM01602

### NOTICE

**Do not continue to run the engine if the low oil pressure alert device has activated. Serious engine damage will occur.**

EMU26806

## Alert system

ECM00093

### NOTICE


**Do not continue to operate the engine if an alert device has activated. Consult your Yamaha dealer if the problem cannot be located and corrected.**

EMU43754


### Overheat alert

This engine has an overheat-alert device. If the engine temperature rises too high, the alert device will activate.


- The engine speed will automatically decrease to 2000–3500 r/min.
- The overheat-alert indicator will light or blink (if equipped).



ZMU01757




ZMU05422




ZMU05231

- The buzzer will sound (if equipped on the tiller handle, remote control box, or main switch panel).



ZMU01758




ZMU05326


If the alert system has activated, stop the engine and check the cooling water inlets:

- Check trim angle to be sure that the cooling water inlet is submerged.
- Check the cooling water inlet for clogging.

# Engine control system



ZMU03604




ZMU05232

EMU26869

## Low oil pressure alert


If the oil pressure drops too low, the alert device will activate.

- The engine speed will automatically decrease to about 2000–3500 r/min.
- The low oil pressure-alert indicator will light or blink (if equipped).




ZMU03609

- The buzzer will sound (if equipped).




ZMU01758



ZMU05326

TACH



ZMU05431

If the alert system has activated, stop the engine as soon as it is safe to do so. Check the oil level and add oil as needed. If the oil level is correct, consult your Yamaha dealer.

EMU26903

## Installation

The information presented in this section is intended as reference only. It is not possible to provide complete instructions for every possible boat and motor combination. Proper mounting depends in part on experience and the specific boat and motor combination.

EWMO1591




### WARNING

- **Overpowering a boat could cause severe instability. Do not install an outboard motor with more horsepower than the maximum rating on the capacity plate of the boat. If the boat does not have a capacity plate, consult the boat manufacturer.**
- **Improper mounting of the outboard motor could result in hazardous conditions such as poor handling, loss of control, or fire hazards. For permanently mounted models, your dealer or other person experienced in proper rigging should mount the motor.**

EMU33471

### Mounting the outboard motor

The outboard motor should be mounted so that the boat is well balanced. Otherwise, the boat could be hard to steer. For single-engine boats, mount the outboard motor on the centerline (keel line) of the boat.



ZMU01760

1. Center line (keel line)

EMU26937


### Mounting height (boat bottom)

The mounting height of your outboard motor affects its efficiency and reliability. If it is mounted too high, propeller ventilation may occur, which will reduce propulsion due to excessive propeller slip, and the water intakes for the cooling system may not get an adequate water supply, which can cause engine overheating. If the engine is mounted too low, water resistance (drag) will increase, thereby reducing engine efficiency and performance.

Most commonly, an outboard motor should be mounted so that the anti-cavitation plate is in alignment with the bottom of the boat. The optimum mounting height of the outboard motor is affected by the boat/motor combination and the desired use. Test runs at different heights can help determine the optimum mounting height. Consult your Yamaha dealer or boat manufacturer for further information on determining the proper mounting height.

# Installation

---



## 1. Idle hole

ECM01635

### NOTICE

- Make sure that the idle hole is high enough to prevent water from entering the engine even if the boat is stationary with the maximum load.
- Incorrect engine height or obstructions to the smooth flow of water (such as the design or condition of the boat, or accessories, such as transom ladders or depth finder transducers) can create airborne water spray while the boat is cruising. If the outboard motor is operated continuously in the presence of airborne water spray, enough water could enter the engine through the air intake opening in the top cowling to cause severe engine damage. Remove the cause of the airborne water spray.

EMU36382

## First-time operation

EMU36393

### Fill engine oil

The engine is shipped from the factory without engine oil. If your dealer did not fill the oil, you must fill it before starting the engine. **NOTICE: Check that the engine is filled with oil before first-time operation to avoid severe engine damage.** [ECM01782]

The engine is shipped with the following tag, which should be removed after engine oil is filled for the first time. For more information on checking the engine oil level, see page 48.



EMU30175

### Breaking in engine

Your new engine requires a period of break-in to allow mating surfaces of moving parts to wear in evenly. Correct break-in will help

ensure proper performance and longer engine life. **NOTICE: Failure to follow the break-in procedure could result in reduced engine life or even severe engine damage.** [ECM00802]

EMU27086

### Procedure for 4-stroke models

Your new engine requires a period of 10 hours break-in to allow mating surfaces of moving parts to wear in evenly.

#### TIP:

Run the engine in the water, under load (in gear with a propeller installed) as follows. For 10 hours for breaking in engine avoid extended idling, rough water and crowded areas.

- (1) For the first hour of operation:  
Run the engine at varying speeds up to 2000 r/min or approximately half throttle.
- (2) For the second hour of operation:  
Increase engine speed as much as necessary to put the boat on plane (but avoid full-throttle operation), then back off on the throttle while keeping the boat at a planing speed.
- (3) Remaining 8 hours:  
Run the engine at any speed. However, avoid operating at full throttle for more than 5 minutes at a time.
- (4) After the first 10 hours:  
Operate the engine normally.

EMU36402

### Getting to know your boat

All boats have unique handling characteristics. Operate cautiously while you learn how your boat handles under different conditions and various trim angles (see page 59).

# Operation

EMU36414

## Checks before starting engine

EWMO1922

### **WARNING**

If any item in “Checks before starting engine” is not working properly, have it inspected and repaired before operating the outboard motor. Otherwise, an accident could occur.

ECM00121

### **NOTICE**

Do not start the engine out of water. Overheating and serious engine damage can occur.

EMU36422


## Fuel level

Be sure you have plenty of fuel for your trip. A good rule is to use 1/3 of your fuel to get to the destination, 1/3 to return, and to keep 1/3 as an emergency reserve. With the boat level on a trailer or in the water, turn the key to “ON” (on) and check the fuel level. For fuel filling instructions, see page 51.

EMU36573

## Remove the top cowling

For the following checks, remove the top cowling from the bottom cowling. To remove the top cowling, release the cowling lock lever and lift off the top cowling.



EMU36443

## Fuel system

EWMO0061

### **WARNING**

Gasoline and its vapors are highly flammable and explosive. Keep away from sparks, cigarettes, flames, or other sources of ignition.

EWMO0911

### **WARNING**

Leaking fuel can result in fire or explosion.

- Check for fuel leakage regularly.
- If any fuel leakage is found, the fuel system must be repaired by a qualified mechanic. Improper repairs can make the outboard unsafe to operate.

EMU36453

## Check for fuel leaks



- Check for fuel leaks or gasoline fumes in the boat.
- Check for fuel leakage from the fuel system.
- Check the fuel tank and fuel lines for cracks, swellings, or other damage.

EMU36472

## Check the fuel filter

Check that the fuel filter is clean and free of water. If enough water to raise the float ring is found in the fuel, or if a significant amount

of debris is found, the fuel tank should be checked and cleaned by a Yamaha dealer.



EMU36904

## Controls


### Tiller handle models

- (1) Move the tiller handle fully to the left and right to make sure operation is smooth.
- (2) Turn the throttle grip from the fully closed to the fully open position. Make sure that it turns smoothly and that it completely returns to the fully closed position.
- (3) Look for loose or damaged connections of the throttle and shift cables.

### Remote control models

- (1) Turn the steering wheel fully to the left and right and make sure operation is smooth and unrestricted throughout the whole range with no binding or excessive free play.


- (2) Operate the remote control levers several times to make sure there is no hesitation in their travel. Operation should be smooth over the complete range of motion, and each lever should return completely to the idle position.
- (3) Look for loose or damaged connections of the throttle and shift cables.



EMU36484

### Engine shut-off cord (lanyard)

Inspect the engine shut-off cord and clip for damage, such as cuts, breaks, and wear.



1. Clip
2. Engine shut-off cord (lanyard)

EMU40995


### Engine oil

- (1) Place the outboard motor in a vertical position (not tilted). **NOTICE: If the outboard motor is not level, the oil level**

# Operation


**indicated on the oil dipstick may not be accurate.** [ECM01862]

- (2) Remove the oil dipstick and wipe it clean.



1. Oil dipstick

- (3) Insert the oil dipstick completely and remove it again.
- (4) Check that the oil level on the oil dipstick is between the upper and lower marks. Consult your Yamaha dealer if the oil level is not at the proper level or if it appears milky or dirty.



1. Lower mark
2. Oil dipstick
3. Upper mark

EMU27154

## Engine


- Check the engine and engine mounting.

- Look for loose or damaged fasteners.
- Check the propeller for damage.
- Check for engine oil leaks.

EMU36494

## Flushing device

Check that the flushing device's garden hose connector is securely screwed on to the fitting on the bottom cowling. **NOTICE:** If the garden hose connector is not properly connected, cooling water can leak out and the engine can overheat during operation. [ECM01802]



1. Fitting
2. Flushing device


EMU36957

## Installing top cowling


- (1) Be sure that the cowling lock lever is released.
- (2) Be sure that the rubber seal is seated all the way around the top cowling.
- (3) Place the top cowling on the bottom cowling.
- (4) Check to be sure the rubber seal is seated correctly between the top cowling and the bottom cowling.
- (5) Move the cowling lock lever to lock the top cowling as shown. **NOTICE:** If the top cowling is not installed correctly, water spray under the top cowling

**can damage the engine, or the top cowling can blow off at high speeds.**

[ECM01992]



After installing, check the fitting of the top cowling by pushing it with both hands. If the top cowling is loose, have it repaired by your Yamaha dealer.



EMU34582

## Power trim and tilt system


EWM01931



**WARNING**

- **Never get under the lower unit while it is tilted, even when the tilt support lever is locked. Severe injury could occur if the outboard motor accidentally falls.**
- **Body parts can be crushed between the motor and the clamp bracket when the motor is trimmed or tilted.**
- **Be sure no one is near the outboard motor before performing this check.**

- (1) Check the power trim and tilt unit for any sign of oil leaks.
- (2) Operate each of the power trim and tilt switches to check that all switches work.
- (3) Tilt the outboard motor up and check that the trim and tilt rod is pushed out completely.



### 1. Trim and tilt rod

- (4) Check that the trim and tilt rod is free of corrosion or other flaws.
- (5) Tilt the outboard motor down. Check that the trim and tilt rod operates smoothly.

EMU36585

## Battery

Check the battery's charge. If your boat is equipped with a Yamaha digital speedometer, the voltmeter and low battery alert functions will help you monitor the battery's charge. A battery in good condition will provide a minimum of 12 volts. Check that the battery connections are clean, secure and covered by insulating covers. The electrical connections of the battery and cables must be clean and properly connected or the battery will not start the engine.

# Operation

If the battery needs charging, consult your Yamaha dealer or the battery manufacturer's instructions.

EMU2743B

## Filling fuel

EWM01831


### **WARNING**

- Gasoline and its vapors are highly flammable and explosive. Always refuel according to this procedure to reduce the risk of fire and explosion.
- Gasoline is poisonous and can cause injury or death. Handle gasoline with care. Never siphon gasoline by mouth. If you should swallow some gasoline or inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immediately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.


Before refueling, check the following points:

- Ensure the engine is stopped.
- Securely moor the boat in a well-ventilated area and stop the engine. If the boat is trailered, make sure that it is stable.
- Do not smoke and keep away from sparks, flames, static electric discharge, or other sources of ignition.
- If you use a portable container to store and dispense fuel, only use a locally approved GASOLINE container.
- To prevent electrostatic sparks, discharge any built-up static electricity from your body before refueling.

- (1) Disconnect the fuel hose from the fuel tank and tighten the air vent screw on the fuel tank cap.




ZMU06598



ZMU02301

- (2) Remove the fuel tank from the boat.
- (3) Remove the fuel tank cap.
- (4) Fill the fuel tank with fuel. **WARNING! Do not overfill. Otherwise fuel can expand and overflow if the temperature increases.** [EWM02611]



ZMU02834

### **Fuel tank capacity:**

24 L (6.34 US gal, 5.28 Imp.gal)

- (5) Tighten the fuel tank cap securely.

- (6) Wipe up any spilled gasoline immediately with dry rags. Dispose of rags properly according to local laws or regulations.

EMU27453

## Operating engine

EWMO0421


### **WARNING**

- **Before starting the engine, make sure that the boat is tightly moored and that you can steer clear of any obstructions. Be sure there are no swimmers in the water near you.**
- **When the air vent screw is loosened, gasoline vapor will be released. Gasoline is highly flammable, and its vapors are flammable and explosive. Refrain from smoking, and keep away from open flames and sparks while loosening the air vent screw.**
- **This product emits exhaust gases which contain carbon monoxide, a colorless, odorless gas which could cause brain damage or death when inhaled. Symptoms include nausea, dizziness, and drowsiness. Keep cockpit and cabin areas well ventilated. Avoid blocking exhaust outlets.**

EMU2746B


## Sending fuel (portable tank)

- (1) If there is an air vent screw on the fuel tank cap, loosen it 2 or 3 turns.



ZMU02295

- (2) If there is a fuel joint on the motor, align the fuel joint on the fuel line with the fuel joint on the motor and firmly connect the fuel line to the joint while pinching the joint. Then firmly connect the other end of the fuel line to the joint on the fuel tank.




ZMU02024

### **TIP:**

Wipe up any spilled gasoline immediately with dry rags. Dispose of rags properly according to local laws or regulations.

- (3) Squeeze the primer pump, with the arrow pointing up, until you feel it become firm. During engine operation, place the tank horizontally, otherwise fuel cannot be drawn from the fuel tank.

# Operation



ZMU02025

1. Arrow

EMU27497

## Starting engine

EWM01601

### **WARNING**

Before starting the engine, make sure that the boat is tightly moored and that you can steer clear of any obstructions. Be sure there are no swimmers in the water near you.

EMU27597


## Electric start / prime start models

EWM01842

### **WARNING**

- Failure to attach the engine shut-off cord could result in a runaway boat if operator is ejected. Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg while operating. Do not attach the cord to clothing that could tear loose. Do not route the cord where it could become entangled, preventing it from functioning.
- Avoid accidentally pulling the cord during normal operation. Loss of engine power means the loss of most steering control. Also, without engine power, the boat could slow rapidly. This could cause people and objects in the boat to be thrown forward.

- (1) Place the gear shift lever in neutral.




ZMU05215

### TIP:


The start-in-gear protection device prevents the engine from starting except when in neutral.

- (2) Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg. Then install the clip on the other end of the cord into the engine shut-off switch.




ZMU05216

- (3) Place the throttle grip in the “START” (start) position. After the engine starts, return the throttle to the fully closed position.



ZMU05217

- (4) Turn the main switch to “START” (start), and hold it for a maximum of 5 seconds.



ZMU05218

- (5) Immediately after the engine starts, release the main switch and allow it to return to “ON” (on). **NOTICE:** Never turn the main switch to “START” (start) while the engine is running. Do not keep the starter motor turning for more than 5 seconds. If the starter motor is turned continuously for more than 5 seconds, the battery will be quickly discharged, thus making it impossible to start the engine. The starter can also be damaged. If the engine will not start after 5 seconds of cranking, return the main switch to “ON” (on), wait 10 seconds, then crank the engine again. [ECM00193]

## TIP:

- When the engine is cold, it needs to be warmed up. For further information, see page 56.
- If the engine is warm and fails to start, open the throttle slightly and try to start the engine again. If the engine still fails to start, see page 91.

EMU27666


## Electric start and remote control models

EW001842

### **WARNING**

- Failure to attach the engine shut-off cord could result in a runaway boat if operator is ejected. Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg while operating. Do not attach the cord to clothing that could tear loose. Do not route the cord where it could become entangled, preventing it from functioning.
- Avoid accidentally pulling the cord during normal operation. Loss of engine power means the loss of most steering control. Also, without engine power, the boat could slow rapidly. This could cause people and objects in the boat to be thrown forward.

- (1) Place the remote control lever in neutral.




ZMU01771

# Operation


## TIP:

The start-in-gear protection device prevents the engine from starting except when in neutral.

- (2) Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg. Then install the clip on the other end of the cord into the engine shut-off switch.



- (3) Turn the main switch to "ON" (on).
- (4) Turn the main switch to "START" (start), and hold it for a maximum of 5 seconds.



- (5) Immediately after the engine starts, release the main switch and allow it to return to "ON" (on). **NOTICE:** Never turn the main switch to "START" (start) while the engine is running. Do not keep the starter motor turning for more than 5 seconds. If the starter motor is turned continuously for more than 5 seconds, the battery will be

quickly discharged, thus making it impossible to start the engine. The starter can also be damaged. If the engine will not start after 5 seconds of cranking, return the main switch to "ON" (on), wait 10 seconds, then crank the engine again. [ECM00193]

## TIP:

- When the engine is cold, it needs to be warmed up. For further information, see page 56.
- If the engine is warm and fails to start, open the throttle slightly and try to start the engine again. If the engine still fails to start, see page 91.

EMU36511

## Checks after starting engine

EMU36524


### Cooling water

Check for a steady flow of water from the cooling water pilot hole. A continuous flow of water from the pilot hole indicates that the water pump is pumping water through the cooling water passages. If the cooling water passages are frozen, it may take a while for water to start flowing out of the pilot hole.

ECM01811

### NOTICE

If water is not flowing out of the pilot hole at all times while the engine is running, overheating and serious damage could occur. Stop the engine and check whether the cooling water inlet on the lower case or the cooling water pilot hole is blocked. Consult your Yamaha dealer if the problem cannot be located and corrected.



EMU27671

## Warming up engine

EMU27718

### Manual start and electric start models

- (1) After starting the engine, allow it to idle for 3 minutes to warm up. **NOTICE:** Failure to do so will shorten engine life. [ECM04550]
- (2) Be sure the low oil pressure-alert indicator goes off after starting the engine. **NOTICE:** If the low oil pressure-alert indicator blinks after the engine starts, stop the engine. Otherwise, serious engine damage could occur. Check the oil level and add engine oil if necessary. Consult your Yamaha dealer if the cause for the low oil pressure alert cannot be found. [ECM01832]

EMU36532

## Checks after engine warm up

EMU36542

### Shifting

While the boat is tightly moored, and without applying throttle, confirm that the engine shifts smoothly into forward and reverse, and back to neutral.

EMU36981

### Stop switches

- Turn the main switch to “OFF”, or press the engine stop button and make sure the engine stops.
- Confirm that removing the clip from the engine shut-off switch stops the engine.
- Confirm that the engine cannot be started with the clip removed from the engine shut-off switch.

EMU49320

## Shifting

EWMO0181

### WARNING

Before shifting, make sure there are no swimmers or obstacles in the water near you.


ECM01611

### NOTICE

Warm up the engine before shifting into gear. Until the engine is warm, the idle speed may be higher than normal. High idle speed can prevent you from shifting back to neutral. If this occurs, stop the engine, shift to neutral, then restart the engine and allow it to warm up.

### To shift out of neutral

- (1) Pull the neutral interlock trigger up (if equipped).




ZMU01727

1. Neutral interlock trigger


# Operation

- (2) Move the remote control lever / gear shift lever to the forward position or reverse position [about 35° (a detent can felt) for remote control models].


Be sure to check that the tilt lock lever is in the lock/down position (if equipped) before operating in reverse.



ZMU05460




ZMU05674




ZMU03643

To shift from in gear (forward/reverse) to neutral

- (1) Close the throttle so that the engine slows to idle speed.




ZMU05462



ZMU05219


- (2) After the engine is at idle speed in gear, move the remote control lever / gear shift lever to the neutral position.



ZMU01771

## TIP:

Tiller handle models: The gear shift lever operates only when the throttle grip is in the fully closed position.



ZMU05215

EMU31743

## Stopping boat

EWM01511

### **WARNING**

- **Do not use the reverse function to slow down or stop the boat as it could cause you to lose control, be ejected, or impact the steering wheel or other parts of the boat. This could increase the risk of serious injury. It could also damage the shift mechanism.**
- **Do not shift into reverse while traveling at planing speeds. Loss of control, boat swamping, or damage to the boat could occur.**

The boat is not equipped with a separate braking system. Water resistance stops it after the throttle lever is moved back to idle. The stopping distance varies depending on gross weight, water surface conditions, and wind direction.

EMU30881


## Trolling

EMU30891

### Adjusting trolling speed

The trolling speed on outboard motors equipped with the variable trolling RPM

switches can be adjusted approximately 50 r/min with each press of a switch.



ZMU05222

1. "UP" switch
2. "DN" switch

To increase the trolling speed, press the "UP" switch.

To decrease the trolling speed, press the "DN" switch.

### TIP:

- The trolling speed changes approximately 50 r/min each time a switch is pressed.
- If the trolling speed has been adjusted, the engine returns to the normal trolling speed when the engine is stopped and restarted or when the engine speed exceeds approximately 3000 r/min.

EMU27824

## Stopping engine


Before stopping the engine, first let it cool off for a few minutes at idle or low speed. Stopping the engine immediately after operating at high speed is not recommended.

EMU2784A


### Procedure

- (1) Push and hold the engine stop button or turn the main switch to "OFF" (off).


# Operation



ZMU01779




ZMU05223




ZMU05209

- (2) After stopping the engine, disconnect the fuel line if there is a fuel joint on the outboard motor.



ZMU07082

- (3) Tighten the air vent screw on the fuel tank cap (if equipped).



ZMU02301

- (4) Remove the key if the boat will be left unattended.

## TIP:

The engine can also be stopped by pulling the cord and removing the clip from the engine shut-off switch, then turning the main switch to "OFF" (off).

EMU27865

## Trimming outboard motor

EWV00741




### WARNING

Excessive trim for the operating conditions (either trim up or trim down) can cause boat instability and can make steering the boat more difficult. This increases the possibility of an accident. If the boat begins to feel unstable or is hard

to steer, slow down and/or readjust the trim angle.

The trim angle of the outboard motor helps determine the position of the bow of the boat in the water. Correct trim angle will help improve performance and fuel economy while reducing strain on the engine. Correct trim angle depends upon the combination of boat, engine, and propeller. Correct trim is also affected by variables such as the load in the boat, sea conditions, and running speed.



1. Trim operating angle

EMU27889

## Adjusting trim angle (Power trim and tilt)

EWM00754




**WARNING**

- Be sure all people are clear of the outboard motor when adjusting the trim angle. Body parts can be crushed be-

tween the motor and the clamp bracket when the motor is trimmed or tilted.


- Use caution when trying a trim position for the first time. Increase speed gradually and watch for any signs of instability or control problems. Improper trim angle can cause loss of control.
- If equipped with a power trim and tilt switch located on the bottom cowling, use the switch only when the boat is at a complete stop with the engine off. Do not adjust the trim angle with this switch while the boat is moving.

Adjust the outboard motor trim angle using the power trim and tilt switch.



ZMU01781

1. Power trim and tilt switch



ZMU05224

1. Power trim and tilt switch

# Operation

To raise the bow (trim-out), press the switch “UP” (up).

To lower the bow (trim-in), press the switch “DN” (down).

Make test runs with the trim set to different angles to find the position that works best for your boat and operating conditions.

EMU27893


## Adjusting trim angle for hydro tilt models

EWM00492

### WARNING

- **Stop the engine before adjusting the trim angle.**
- **Be sure all people are clear of the outboard motor when adjusting the trim angle, also be careful not to pinch any body parts between the drive unit and clamp bracket.**
- **Use caution when trying a trim position for the first time. Increase speed gradually and watch for any signs of instability or control problems. Improper trim angle can cause loss of control.**

- (1) Stop the engine.
- (2) Place the tilt lock lever in the release position.



- (3) Hold the rear of the top cowling with one hand and tilt the engine to the desired angle.

- (4) Place the tilt lock lever back into the lock position to support the engine.

To raise the bow (“trim-out”), tilt the engine up.


To lower the bow (“trim-in”), tilt the engine down.

Make test runs with the trim set to different angles to find the position that works best for your boat and operating conditions.

EMU27913

## Adjusting boat trim


When the boat is on plane, a bow-up attitude results in less drag, greater stability and efficiency. This is generally when the keel line of the boat is up about 3 to 5 degrees. With the bow up, the boat may have a greater tendency to steer to one side or the other. Compensate for this as you steer. When the bow of the boat is down, it is easier to accelerate from a standing start onto plane.



ZMU01784

## Bow Up


Too much trim-out puts the bow of the boat too high in the water. Performance and economy are decreased because the hull of the boat is pushing the water and there is more air drag. Excessive trim-out can also cause the propeller to ventilate, which reduces performance further, and the boat may “porpoise” (hop in the water), which could throw the operator and passengers overboard.



ZMU01785

## Bow Down

Too much trim-in causes the boat to “plow” through the water, decreasing fuel economy and making it hard to increase speed. Operating with excessive trim-in at higher speeds also makes the boat unstable. Resistance at the bow is greatly increased, heightening the danger of “bow steering” and making operation difficult and dangerous.



ZMU01786

## TIP:

Depending on the type of boat, the outboard motor trim angle may have little effect on the trim of the boat when operating.

EMU27936

## Tilting up and down

If the engine will be stopped for some time or if the boat is moored in shallows, the outboard motor should be tilted up to protect the propeller and lower casing from damage

by collision with obstructions, and also to reduce salt corrosion.

EWMO0223

## WARNING

Make sure that no one is near the outboard motor when tilting the outboard motor up or down. Otherwise, body parts could be crushed between the outboard motor and the clamp bracket.

EWMO0251

## WARNING

Leaking fuel is a fire hazard. If there is a fuel joint on the outboard motor, disconnect the fuel line or close the fuel cock if the engine will be tilted for more than a few minutes. Otherwise fuel may leak.

ECMO0242

## NOTICE



- Before tilting the outboard motor, stop the engine by following the procedure on page 58. Never tilt the outboard motor while the engine is running. Severe damage from overheating can result.
- Do not tilt up the engine by pushing the tiller handle (if equipped) because this could break the handle.

EMU2799A


## Procedure for tilting up (hydro tilt models)

- (1) Place the remote control lever / gear shift lever in neutral.

# Operation




- (2) Place the tilt lock lever in the release position.



- (3) Hold the rear of the top cowling with one hand, tilt the engine up, and turn the tilt support lever toward you or tilt support knob into the clamp bracket, and then place the tilt lock lever back into the lock position to support the outboard motor.

**NOTICE:** Do not use the tilt support lever or knob when trailering the boat. The outboard motor could shake


loose from the tilt support and fall. If the motor cannot be trailered in the normal running position, use an additional support device to secure it in the tilt position. For more detailed information, see page 69. [ECM01642]




EMU49341


## Procedure for tilting up (power trim and tilt models)

- (1) Place the remote control lever / gear shift lever in neutral.






ZMU05215




ZMU05226

- (2) Press the power trim and tilt switch “UP” (up) until the outboard motor has tilted up completely.




ZMU01787



ZMU07920

- (3) Set the tilt support lever to support the engine. **WARNING!** After tilting the outboard motor, be sure to support it with the tilt support knob or tilt support lever. Otherwise the outboard motor could fall back down suddenly if oil in the power trim and tilt unit or in the power tilt unit loses pressure.

[EWM00263] **NOTICE:** Do not use the tilt support lever or knob when trailering the boat. The outboard motor could shake loose from the tilt support and fall. If the motor cannot be trailered in the normal running position, use an additional support device to secure it in the tilt position. For more detailed information, see page 69. [ECM01642]



ZMU03640

- (4) Once the outboard motor is supported with the tilt support lever, press the power trim and tilt switch “DN” (down) to retract the trim rods. **NOTICE:** Make sure


# Operation

that the trim rods retract completely during mooring. This protects the rods from marine growth and corrosion, which could damage the power trim and tilt mechanism. [ECM00254]


EMU34481

## Procedure for tilting down (hydro tilt models)


- (1) Release the tilt lock lever.



- (2) Hold the rear of the top cowl with one hand, tilt the outboard motor up slightly and pull out the tilt support knob or return the tilt support lever.




- (3) Slowly tilt the outboard motor down.
- (4) Place the tilt lock lever in the lock position.




EMU35517

## Procedure for tilting down (power trim and tilt models)


- (1) Push the power trim and tilt switch "UP" (up) until the outboard motor is supported by the tilt rod and the tilt support lever becomes free.
- (2) Release the tilt support lever.




- (3) Push the power trim and tilt switch "DN" (down) to lower the outboard motor to the desired position.



ZMU01936



ZMU07921



ZMU05228

EMU28063

## Shallow water

EMU28082

### Hydro tilt models

The outboard motor can be tilted up partially to allow operation in shallow water.

EWMO0272


### WARNING

- Run the boat at the lowest possible speed when using the shallow water cruising system.
- Use extra care when operating in reverse. Too much reverse thrust can cause the outboard motor to lift out of the water, increasing the chance of accident and personal injury.

ECM00261

### NOTICE

Do not tilt the outboard motor up so that the cooling water inlet on the lower unit is above the surface of the water when setting up for and cruising in shallow water. Otherwise severe damage from overheating can result.






EMU28176


### Procedure for hydro tilt models

- (1) Place the remote control lever / gear shift lever in neutral.

# Operation



- (2) Pull the tilt lock lever up to the release position.



- (3) Slightly tilt the outboard motor up to the desired position and push the tilt lock lever down to the lock position.
- (4) To return the outboard motor to the normal running position, pull the tilt lock lever up to the release position and slowly tilt the outboard motor down.
- (5) Push the tilt lock lever down to the lock position.

EMU32852

## Power trim and tilt models

The outboard motor can be tilted up partially to allow operation in shallow water.

ECM00261


### NOTICE


**Do not tilt the outboard motor up so that the cooling water inlet on the lower unit is above the surface of the water when setting up for and cruising in shallow water. Otherwise severe damage from overheating can result.**

EMU32917

## Procedure for power trim and tilt models


- (1) Place the remote control lever / gear shift lever in neutral.






ZMU05215

- (2) Slightly tilt the outboard motor up to the desired position using the power trim and tilt switch. **WARNING! Using the power trim and tilt switch on the bottom cowling while the boat is moving or engine is on could increase the risk of falling overboard and could distract the operator, increasing the risk of collision with another boat or an obstacle.** [EWM01851]



ZMU01935



ZMU05226

- (3) To return the outboard motor to the normal running position, press the power trim and tilt switch and slowly tilt the outboard motor down.

EMU28196

## Cruising in other conditions

### Cruising in salt water

After operating in salt water, flush the cooling water passages with fresh water to prevent them from becoming clogged. Also rinse the outside of the outboard motor with fresh water.

### Cruising in muddy, turbid, or acidic water

Yamaha strongly recommends that you use the optional chromium-plated water pump kit (see page 19) if you use the outboard motor in acidic water or water with a lot of sediment in it, such as muddy or turbid (cloudy) water. After operating in such water, flush the cooling passages with fresh water to prevent corrosion. Also rinse the outside of the outboard motor with fresh water.

# Maintenance

EMU2822C

## Transporting and storing outboard motor

EWM02621

### WARNING

- **USE CARE** when transporting fuel tank, whether in a boat or car.
- **DO NOT** fill fuel container to maximum capacity. Gasoline will expand considerably as it warms up and can build up pressure in the fuel container. This can cause fuel leakage and a potential fire hazard.
- Leaking fuel is a fire hazard. When transporting and storing the outboard motor, disconnect the fuel line from the outboard motor to prevent fuel from leaking.
- Never get under the outboard motor while it is tilted. Severe injury could occur if the outboard motor accidentally falls.
- Do not use the tilt support lever or knob when trailering the boat. The outboard motor could shake loose from the tilt support and fall. If the outboard motor cannot be trailered in the normal running position, use an additional support device to secure it in the tilt position.

ECM02441

### NOTICE


When storing the outboard motor for prolonged time, fuel must be drained from the fuel tank. The deteriorated fuel could clog the fuel line causing engine start difficulty or malfunction.

When storing or transporting the outboard motor or when the outboard motor is tilted for a prolonged time for mooring or trailering

the boat, make sure to follow the procedure listed below.

- Disconnect the fuel hose from the outboard motor.
- Tighten the fuel tank cap and its air vent screw.

The outboard motor should be transported and stored in the normal running position. If there is insufficient road clearance in this position, then trailer the outboard motor in the tilt position using a motor support device such as a transom saver bar. Consult your Yamaha dealer for further details.



ZMU03659

EMU28293

## Storing outboard motor

When storing your Yamaha outboard motor for prolonged periods of time (2 months or longer), several important procedures must be performed to prevent excessive damage. It is advisable to have your outboard motor serviced by an authorized Yamaha dealer prior to storage. However, you, the owner, with a minimum of tools, can perform the following procedures.

ECM00602

### NOTICE

- **To prevent problems which can be caused by oil entering the cylinder from the sump, keep the outboard motor in the attitude shown when transporting**

and storing it. If storing or transporting the outboard motor on its side (not upright), put it on a cushion after draining the engine oil.

- Do not place the outboard motor on its side before the cooling water has drained from it completely. Otherwise, water may enter the cylinder through the exhaust port and cause engine trouble.
- Store the outboard motor in a dry, well-ventilated place, not in direct sunlight.
- Drain the remaining gasoline from the vapor separator. Gasoline left in the vapor separator for a prolonged period of time will break down and could cause damage to the fuel line.

EMU28306

## Procedure

EMU41482

### Flushing with the flushing attachment

ECM02131


#### NOTICE

**Do not run the engine without supplying it with cooling water. Either the engine water pump will be damaged or the engine will be damaged from overheating.**

Cooling system flushing is essential to prevent the cooling system from clogging up with salt, sand, or dirt. In addition, fogging/lubricating of the engine is mandatory to prevent excessive engine damage due to rust. Perform the flushing and fogging at the same time.

- (1) Wash the outboard motor body using fresh water. **NOTICE: Do not spray water into the air intake.** [ECM01841] For further information, see page 73.
- (2) Disconnect the fuel line from the outboard motor.

- (3) Remove the engine top cowl, fly-wheel cover, and propeller. For further details, see page 85.
- (4) Install the flushing attachment over the cooling water inlet. **NOTICE: Do not run the engine without supplying it with cooling water. Either the engine water pump will be damaged or the engine will be damaged from overheating. Before starting the engine, be sure to supply water to the cooling water passages. Avoid running the outboard motor at high speed while on the flushing attachment, otherwise overheating could occur.** [ECM02001]



ZMU01830

1. Flushing attachment

#### TIP:


- A flushing attachment is available from your Yamaha dealer.
  - When using the flushing attachment, maintain adequate water pressure and a steady water flow.
- (5) Run the engine at a fast idle for a few minutes in neutral position. **WARNING! Do not touch or remove electrical parts when starting or during operation. Keep hands, hair, and clothes away from the flywheel and other rotating parts while the engine is running.** [EWM00092]

# Maintenance

## TIP:


If the overheat alert device is activated, turn the engine off, and consult your Yamaha dealer.

- (6) Just prior to turning off the engine, quickly spray “Fogging Oil” on to the silencer cover. When properly done, the engine will almost stall.




## TIP:


If the “Fogging Oil” is not available, remove the spark plug(s). Pour a teaspoonful of clean engine oil into each cylinder. Crank several times manually. Replace the spark plug(s).



- (7) Drain the remained gasoline in the vapor separator with a container. Loosen the drain screw, and then remove the cap. Push in the air valve with a screwdriver to introduce air into the float chamber, so that the gasoline will drain smoothly. Then, tighten the drain screw.



1. Drain screw



1. Air valve  
2. Cap

- (8) Remove the flushing attachment.  
(9) Drain the cooling water completely out of the motor. Clean the body thoroughly.  
(10) Install the flywheel cover, propeller, and top cowling.  
(11) Store the fuel tank in a dry, well-ventilated place, not in direct sunlight.

EMU41072

## Lubrication

- (1) Change the gear oil. For instructions, see page 87. Check the gear oil for the

presence of water that indicates a leaky seal. Seal replacement should be performed by an authorized Yamaha dealer prior to use.

- (2) Lubricate all grease fittings. For further details, see page 79.

## TIP:

For long-term storage, fogging the engine with fogging oil is recommended. Contact your Yamaha dealer for information about fogging oil and procedures for your outboard motor.

EMU28446

## Flushing power unit


Perform this procedure right after operation for the most thorough flushing.

EGM01531

### NOTICE

**Do not perform this procedure while the engine is running. The water pump may be damaged and severe damage from overheating can result.**

- (1) After shutting off the engine, unscrew the garden hose connector from the fitting on the bottom cowling.



1. Fitting
  2. Garden hose adapter
  3. Garden hose connector
- (2) Screw the garden hose adapter onto a garden hose, which is connected to a fresh water supply, and then connect it to the garden hose connector.
  - (3) With the engine off, turn on the water tap and let the water flush through the cooling passages for about 15 minutes. Turn off the water and disconnect the garden hose adapter from the garden hose connector.
  - (4) Reinstall the garden hose connector onto the fitting on the bottom cowling. Tighten the connector securely.  
**NOTICE: Do not leave the garden hose connector loose on the bottom cowling fitting or let the hose hang**

# Maintenance

free during normal operation. Water will leak out of the connector instead of cooling the engine, which can cause serious overheating. Be sure the connector is tightened securely on the fitting after flushing the engine.

[ECM00542]

## TIP:


- When flushing the engine with the boat in the water, tilting up the outboard motor until it is completely out of the water will achieve better results.
- For cooling system flushing instructions, see page 69.

EMU44342

## Cleaning the outboard motor

When cleaning the outboard motor, the top cowling must be installed.

- (1) Wash the exterior of the outboard motor using fresh water. **NOTICE: Do not spray water into the air intake.** [ECM01841]



ZMU07861

1. Air intake
- (2) Drain the cooling water completely out of the outboard motor. Clean the body thoroughly.

EMU28463

## Checking painted surface of outboard motor

Check the outboard motor for scratches, nicks, or flaking paint. Areas with damaged paint are more likely to corrode. If necessary, clean and paint the areas. Touch-up paint is available from your Yamaha dealer.

EMU2847G

## Periodic maintenance

EWMO1872



These procedures require mechanical skills, tools, and supplies. If you do not have the proper skills, tools, or supplies to perform a maintenance procedure, have a Yamaha dealer or other qualified mechanic do the work.

The procedures involve disassembling the motor and exposing dangerous parts. To reduce the risk of injury from moving, hot, or electrical parts:

- Turn off the engine and keep the key(s) and engine shut-off cord (lanyard) with you when you perform maintenance unless otherwise specified.
- The power trim and tilt switches operate even when the ignition key is off. Keep people away from the switches whenever working around the motor. When the motor is tilted, keep away from the area under it or between it and the clamp bracket. Be sure no one is in this area before operating the power trim and tilt mechanism.
- Allow the engine to cool before handling hot parts or fluids.
- Always completely reassemble the motor before operation.

EMU28512

## Replacement parts

If replacement parts are necessary, use only genuine Yamaha parts or parts of equivalent design and quality. Any part of inferior quality may malfunction, and the resulting loss of control could endanger the operator and passengers. Yamaha genuine parts and accessories are available from your Yamaha dealer.

EMU34152

## Severe operating conditions

Severe operating conditions involve one or more of the following types of operation on a regular basis:

- Operating continuously at or near maximum engine speed (rpm) for many hours
- Operating continuously at a low engine speed (rpm) for many hours
- Operating without sufficient time for engine to warm up and cool down
- Frequent quick acceleration and deceleration
- Frequent shifting
- Frequently starting and stopping the engine(s)
- Operation that fluctuates often between light and heavy cargo loads

Outboard motors operating under any of these above conditions require more frequent maintenance. Yamaha recommends that you do this service twice as often as specified in the maintenance chart. For example, if a particular service should be done at 50 hours, do it instead at 25 hours. This will help prevent more rapid deterioration of engine components.

# Maintenance

EMU46074

## Maintenance chart 1

### TIP:

- Refer to the sections in this chapter for explanations of each owner-specific action.
- The maintenance cycle on these charts assume usage of 100 hours per year and regular flushing of the cooling water passages. Maintenance frequency should be adjusted when operating the engine under adverse conditions such as extended trolling.
- Disassembly or repairs may be necessary depending on the outcome of maintenance checks.
- Expendable or consumable parts and lubricants will lose their effectiveness over time and through normal usage regardless of the warranty period.
- When operating in salt water, muddy, other turbid (cloudy), acidic water, the engine should be flushed with clean water after each use.

The “●” symbol indicates the check-ups which you may carry out yourself.

The “○” symbol indicates work to be carried out by your Yamaha dealer.

| Item                                     | Actions                                            | Initial                | Every                 |                        |                        |        | Page |
|------------------------------------------|----------------------------------------------------|------------------------|-----------------------|------------------------|------------------------|--------|------|
|                                          |                                                    | 20 hours<br>(3 months) | 100 hours<br>(1 year) | 300 hours<br>(3 years) | 500 hours<br>(5 years) |        |      |
| Anode(s) (external)                      | Inspection or re-<br>placement as nec-<br>essary   |                        | ●/○                   |                        |                        | 88     |      |
| Anode(s) (internal)<br>*1                | Inspection or re-<br>placement as nec-<br>essary   |                        | ○                     |                        |                        | —      |      |
| Anode(s) (internal)<br>*2                | Replacement                                        |                        |                       |                        | ○                      | —      |      |
| Battery (electrolyte<br>level, terminal) | Inspection                                         | ●/○                    | ●/○                   |                        |                        | 89     |      |
| Battery (electrolyte<br>level, terminal) | Fill, charging or re-<br>placing as neces-<br>sary |                        | ○                     |                        |                        | —      |      |
| Cooling water leak-<br>age               | Inspection or re-<br>placement as nec-<br>essary   | ○                      | ○                     |                        |                        | —      |      |
| Cowling lock lever                       | Inspection                                         |                        | ●/○                   |                        |                        | 47, 49 |      |
| Engine starting<br>condition/noise       | Inspection                                         | ●/○                    | ●/○                   |                        |                        | 52     |      |
| Engine idle speed/<br>noise              | Inspection                                         | ●/○                    | ●/○                   |                        |                        | 80     |      |
| Engine oil                               | Replacement                                        | ●/○                    | ●/○                   |                        |                        | 81     |      |
| Engine oil filter<br>(cartridge)         | Replacement                                        |                        | ●/○                   |                        |                        | 83     |      |

| Item                                 | Actions                                                      | Initial                | Every                 |                        |                        |    | Page |
|--------------------------------------|--------------------------------------------------------------|------------------------|-----------------------|------------------------|------------------------|----|------|
|                                      |                                                              | 20 hours<br>(3 months) | 100 hours<br>(1 year) | 300 hours<br>(3 years) | 500 hours<br>(5 years) |    |      |
| Fuel filter (can be disassembled)    | Inspection or re-<br>placement as nec-<br>essary             | ●/○                    | ●/○                   |                        |                        | 47 |      |
| Fuel line (High pressure)            | Inspection                                                   | ●                      | ●                     |                        |                        | —  |      |
| Fuel line (High pressure)            | Inspection or re-<br>placement as nec-<br>essary             | ○                      | ○                     |                        |                        | —  |      |
| Fuel line (Low pres-<br>sure)        | Inspection                                                   | ●                      | ●                     |                        |                        | —  |      |
| Fuel line (Low pres-<br>sure)        | Inspection or re-<br>placement as nec-<br>essary             | ○                      | ○                     |                        |                        | —  |      |
| Fuel pump                            | Inspection or re-<br>placement as nec-<br>essary             |                        |                       | ○                      |                        | —  |      |
| Fuel/engine oil leakage              | Inspection                                                   | ○                      | ○                     |                        |                        | —  |      |
| Gear oil                             | Replacement                                                  | ●/○                    | ●/○                   |                        |                        | 87 |      |
| Greasing points                      | Greasing                                                     | ●/○                    | ●/○                   |                        |                        | 79 |      |
| Clamp bracket bolt (through tube)    | Inspection and greasing                                      |                        | ○                     |                        |                        | —  |      |
| Impeller/water pump housing          | Inspection or re-<br>placement as nec-<br>essary             |                        | ○                     |                        |                        | —  |      |
| Impeller/water pump housing          | Replacement                                                  |                        |                       | ○                      |                        | —  |      |
| Power trim and tilt unit             | Inspection                                                   | ●/○                    | ●/○                   |                        |                        | 50 |      |
| Propeller/propeller nut/cotter pin   | Inspection or re-<br>placement as nec-<br>essary             | ●/○                    | ●/○                   |                        |                        | 85 |      |
| Shift link/shift ca-<br>ble          | Inspection, adjust-<br>ment or replace-<br>ment as necessary | ○                      | ○                     |                        |                        | —  |      |
| Spark plug(s)                        | Inspection or re-<br>placement as nec-<br>essary             |                        | ●/○                   |                        |                        | 79 |      |
| Spark plug caps/<br>spark plug wires | Inspection or re-<br>placement as nec-<br>essary             | ○                      | ○                     |                        |                        | —  |      |

# Maintenance

| Item                                                        | Actions                                                      | Initial                | Every                 |                        |                        |    | Page |
|-------------------------------------------------------------|--------------------------------------------------------------|------------------------|-----------------------|------------------------|------------------------|----|------|
|                                                             |                                                              | 20 hours<br>(3 months) | 100 hours<br>(1 year) | 300 hours<br>(3 years) | 500 hours<br>(5 years) |    |      |
| Shift Dampener System (SDS) pro-<br>peller damper           | Inspection or re-<br>placement                               |                        | ○                     |                        |                        | —  |      |
| Water from the<br>cooling water pilot<br>hole               | Inspection                                                   | ●/○                    | ●/○                   |                        |                        | 55 |      |
| Throttle link/throt-<br>tle cable                           | Inspection, adjust-<br>ment or replace-<br>ment as necessary | ○                      | ○                     |                        |                        | —  |      |
| Thermostat                                                  | Inspection or re-<br>placement as nec-<br>essary             |                        | ○                     |                        |                        | —  |      |
| Timing belt                                                 | Inspection or re-<br>placement as nec-<br>essary             |                        | ○                     |                        |                        | —  |      |
| Valve clearance                                             | Inspection and ad-<br>justment                               |                        |                       |                        | ○                      | —  |      |
| Cooling water inlet                                         | Inspection                                                   | ●/○                    | ●/○                   |                        |                        | 21 |      |
| Main switch/stop<br>switch                                  | Inspection or re-<br>placement as nec-<br>essary             | ○                      | ○                     |                        |                        | —  |      |
| Wire harness con-<br>nections/wire cou-<br>pler connections | Inspection or re-<br>placement as nec-<br>essary             | ○                      | ○                     |                        |                        | —  |      |
| (Yamaha) Meter/<br>gauge                                    | Inspection                                                   | ○                      | ○                     |                        |                        | —  |      |
| Fuel tank (Yamaha<br>portable tank)                         | Inspection and<br>cleaning as neces-<br>sary                 |                        | ○                     |                        |                        | —  |      |

EMU46230

- \*1 cylinder head, thermostat cover
- \*2 exhaust cover, cooling water passage cover, Rectifier Regulator cover

EMU46083

## Maintenance chart 2

| Item                               | Actions                                          | Every      | Page |
|------------------------------------|--------------------------------------------------|------------|------|
|                                    |                                                  | 1000 hours |      |
| Exhaust guide/<br>exhaust manifold | Inspection or re-<br>placement as nec-<br>essary | ○          | —    |
| Timing belt                        | Replacement                                      | ○          | —    |


# Maintenance

EMU28946

## Greasing

Yamalube grease A (water resistant grease)

Yamaha grease D (corrosion resistant grease; for propeller shaft)



EMU44852

## Inspecting spark plug

The spark plug is an important engine component. The condition of the spark plug can indicate something about the condition of the engine. For example, if the center electrode porcelain is very white, this could indicate an intake air leak or carburetion problem in that cylinder. Do not attempt to diagnose any problems yourself. Instead, take the outboard motor to a Yamaha dealer. You should periodically remove and inspect the spark plug because heat and deposits will cause

the spark plug to slowly break down and erode.

### To remove the spark plug

- (1) Remove the spark plug caps from the spark plugs.
- (2) Remove the spark plug. **WARNING!** When removing or installing a spark plug, be careful not to damage the insulator. A damaged insulator could allow external sparks, which could lead to explosion or fire. [EWM00562]


## To check the spark plug

- (1) Check the condition of the spark plug. If electrode erosion becomes excessive or carbon and other deposits are excessive, replace the spark plug with the specified plug.

### Standard spark plug:

DPR6EB-9 (F40LET, F50LED, F50LET,  
F60HET, FT50NET, FT60JET)  
LKR7E (F40NET, F70BET)

- (2) Measure the spark plug gap using a thickness gauge. If the spark plug gap is out of specification, replace the spark plug with the specified plug.



ZMU02179

1. Spark plug gap
2. Spark plug part number
3. Spark plug I.D. mark (NGK)

### Spark plug gap:

0.8–0.9 mm (0.031–0.035 in)

## To install the spark plug

- (1) Wipe off any dirt from the threads, insulator, and gasket surface of the spark plug.
- (2) Install the spark plug, and then tighten it to the specified torque.

### Spark plug tightening torque:

17 N·m (1.7 kgf·m, 13 lb·ft)

## TIP:

If a torque-wrench is not available when you are reinstalling a spark plug, a good estimate of the correct torque is 1/12 turn past finger-tight. When you are installing a new spark plug, a good estimate of the correct torque is 1/2 turn past finger-tight.

- (3) Install the spark plug caps.

EMU29045

## Inspecting idle speed

EWM00452

### WARNING

- Do not touch or remove electrical parts when starting or during operation.
- Keep hands, hair, and clothes away from the flywheel and other rotating parts while the engine is running.

ECM00491

### NOTICE

This procedure must be performed while the outboard motor is in the water. A flushing attachment or test tank can be used.

If the boat is not equipped with a tachometer for the outboard motor, use a diagnostic tachometer for this procedure. Results may vary depending on whether testing is conducted with the flushing attachment, in a test tank, or with the outboard motor in the water.

- (1) Start the engine and allow it to warm up fully in neutral until it is running smoothly.
- (2) Once the engine has warmed up, verify whether the idle speed is set to specification. For idle speed specifications, see page 14. If you have difficulty verifying the idle speed, or the idle speed requires adjustment, consult a Yamaha dealer or other qualified mechanic.

# Maintenance

EMU3880A

## Changing engine oil

EWM00761

### WARNING

- Avoid draining the engine oil immediately after stopping the engine. The oil is hot and should be handled with care to avoid burns.
- Be sure the outboard motor is securely fastened to the transom or a stable stand.


ECM01711

### NOTICE

Change the engine oil after the first 20 hours of operation or 3 months, and every 100 hours or at 1-year intervals thereafter. Otherwise the engine will wear quickly.


To prevent spilling oil where it could cause damage to nature, it is strongly recommended that you use an oil changer to change the engine oil. If an oil changer is not available, drain the engine oil by removing the drain screw. If you are not familiar with the procedure for changing the engine oil, consult your Yamaha dealer.

- (1) Put the outboard motor in an upright position (not tilted). **NOTICE: If the outboard motor is not level, the oil level indicated on the oil dipstick may not be accurate.** [ECM01862]



ZMU03659

- (2) Start the engine. Warm it up and keep the idle speed for 5-10 minutes.
- (3) Stop the engine and leave it for 5-10 minutes.
- (4) Remove the top cowling.
- (5) Remove the oil filler cap.



ZMU06187


1. Oil changer

- (6) Remove the oil dipstick.
- (7) Insert the tube of the oil changer into the oil dipstick guide, and then extract the engine oil completely.

### TIP:

When using an oil changer, skip steps 8 and 9.

- (8) Prepare a suitable container that holds a larger amount than the engine oil capacity. Remove the drain screw and gasket while holding the container under the drain hole. Let the oil drain completely. Wipe up any spilled oil immediately.



1. Drain screw
2. Gasket

## TIP:

If the oil does not drain easily, change the tilt angle or turn the outboard motor to port and starboard to drain the oil.


- (9) Put a new gasket on the oil drain screw. Apply a light coat of oil to the gasket and install the drain screw.

**Drain screw tightening torque:**  
27 N·m (2.7 kgf·m, 20 lb·ft)


## TIP:

If a torque wrench is not available when you are installing the drain screw, finger tighten the screw just until the gasket comes into contact with the surface of the drain hole. Then tighten 1/4 to 1/2 turn more. Tighten the drain screw to the correct torque with a torque wrench as soon as possible.

- (10) Add the correct amount of oil through the filler hole. Put back the filler cap and the dipstick. **NOTICE: Overfilling the oil could cause leakage or damage. If the oil level is above the upper level mark, drain until the level meets the specified capacity.** [ECM01851]



1. Oil filler cap



1. Oil filler cap

## Recommended engine oil:

YAMALUBE 4 or 4-stroke outboard motor oil

## Engine oil quantity (without oil filter replacement):

1.9 L (2.01 US qt, 1.67 Imp.qt)


## Engine oil quantity (with oil filter replacement):

2.1 L (2.22 US qt, 1.85 Imp.qt)

- (11) Leave the outboard motor for 5-10 minutes.
- (12) Remove the oil dipstick and wipe it clean.
- (13) Insert the dipstick and remove it again. Be sure to completely insert the dipstick into the dipstick guide, otherwise the oil level measurement will be incorrect.

# Maintenance

- (14) Recheck the oil level using the dipstick to be sure the level falls between the upper and lower marks. Consult your Yamaha dealer if the oil level is out of specified level.



ZMU05091

1. Lower mark
2. Oil dipstick
3. Upper mark

- (15) Start the engine and make sure that the low oil pressure-alert indicator remains off. Also, make sure that there are no oil leaks. **NOTICE: If the low oil pressure-alert indicator comes on or if there are oil leaks, stop the engine and find the cause. Continued operation with a problem could cause severe engine damage. Consult your Yamaha dealer if the problem cannot be located and corrected.** [ECM01623]

- (16) Install the top cowling.  
(17) Dispose of used oil according to local regulations.

## TIP:

- For more information on the disposal of used oil, consult your Yamaha dealer.
- Change the oil more often when operating the engine under adverse conditions such as extended trolling.

EMU48110

## Replacing the engine oil filter

EWMM00761




- Avoid draining the engine oil immediately after stopping the engine. The oil is hot and should be handled with care to avoid burns.
- Be sure the outboard motor is securely fastened to the transom or a stable stand.

Yamaha recommends you to have a Yamaha dealer replace the engine oil filter.


If you perform replacement yourself, follow the procedure below. If you have any questions, please consult a Yamaha dealer.

- (1) Drain the engine oil. For further information, see page 81.
- (2) Place a cloth under the engine oil filter.
- (3) Turn the engine oil filter counterclockwise and remove it.




## TIP:

- Wipe up any spilled engine oil.
  - Dispose of the removed engine oil filter in accordance with local regulations.
- (4) Apply engine oil to the O-ring of the engine oil filter.



1. O-ring

- (5) Turn the engine oil filter clockwise and tighten it to the specified torque.



#### Engine oil filter:

18 N·m (1.8 kgf·m, 13 lb·ft)


- (6) Fill up the engine with engine oil. For further information, see page 81.

EMU48060

## Why Yamalube

YAMALUBE oil is a Genuine YAMAHA Part born of the engineers' passion and belief that engine oil is an important liquid engine component. We form teams of specialists in the fields of mechanical engineering, chemistry, electronics and track testing, and have them develop the engine together with the oil it will


use. Yamalube oils take full advantage of the base oil's qualities and blend in the ideal balance of additives to make sure the final oil clears our performance standards. Thus, Yamalube mineral, semisynthetic and synthetic oils have their own distinct characters and value. Yamaha's experience gained over many years of research and development into oil since the 1960's helps make Yamalube the best choice for your Yamaha engine.



EMU29116


## Inspecting wiring and connectors

- Inspect that each connector is engaged securely.
- Inspect that each ground lead is properly secured.



ZMU07106

# Maintenance



EMU32113


## Checking propeller

EWM01882




**You could be seriously injured if the engine accidentally starts when you are near the propeller. Before inspecting, removing, or installing the propeller, place the shift control in neutral, turn the main switch to "OFF" (off) and remove the key, and remove the clip from the engine shut-off switch. Turn off the battery cut-off switch if your boat has one.**

Do not use your hand to hold the propeller when loosening or tightening the propeller nut. Put a wood block between the anti-cavitation plate and the propeller to prevent the propeller from turning.



## Checkpoints

- Check each of the propeller blades for erosion from cavitation or ventilation, or other damage.
- Check the propeller shaft for damage.
- Check the splines for wear or damage.
- Check for fish line tangled around the propeller shaft.



- Check the propeller shaft oil seal for damage.

EMU30663


## Removing propeller

EMU29198

### Spline models

- (1) Straighten the cotter pin and pull it out using a pair of pliers.
- (2) Remove the propeller nut, washer, and spacer (if equipped). **WARNING! Do not use your hand to hold the propeller when loosening the propeller nut.**

[EWM01891]



### 1. Cotter pin

2. Propeller nut
3. Washer
4. Spacer
5. Propeller
6. Thrust washer

- (3) Remove the propeller, washer (if equipped), and thrust washer.

EMU30673

## Installing propeller

EMU46121


### Spline models

ECM00502

#### NOTICE

**Make sure to use a new cotter pin and bend the ends over securely. Otherwise, the propeller could come off during operation and be lost.**

- (1) Apply Yamalube Marine Grease or a corrosion resistant grease to the propeller shaft.
- (2) Install the spacer (if equipped), thrust washer, washer (if equipped), and propeller on the propeller shaft. **NOTICE: Make sure to install the thrust washer before installing the propeller. Otherwise, the lower case and propeller boss could be damaged.** [ECM01882]
- (3) Install the spacer (if equipped) and the washer. Tighten the propeller nut to the specified torque.




ZMU08159

1. Cotter pin
2. Propeller nut
3. Washer
4. Spacer
5. Propeller
6. Thrust washer

#### Propeller nut tightening torque:

34 N·m (3.4 kgf·m, 25 lb·ft)

- (4) Align the propeller nut slot with the propeller shaft hole. Insert a new cotter pin in the hole and bend the cotter pin ends. **NOTICE: Do not reuse the cotter pin. Otherwise, the propeller can come off during operation.** [ECM01892]



ZMU01805

# Maintenance

## TIP:

If the propeller nut slot does not align with the propeller shaft hole after tightening the propeller nut to the specified torque, tighten the nut further to align the slot with the hole.

EMU2928D


## Changing gear oil

EWMO0801

### WARNING

- Be sure the outboard motor is securely fastened to the transom or a stable stand. You could be severely injured if the outboard motor falls on you.
- Never get under the lower unit while it is tilted, even when the tilt support lever or knob is locked. Severe injury could occur if the outboard motor accidentally falls.

- (1) Tilt the outboard motor so that the gear oil drain screw is at the lowest point possible.
- (2) Place a suitable container under the lower unit.
- (3) Remove the gear oil drain screw and gasket. **NOTICE:** If there is an excessive quantity of metal particles on the magnetic gear oil drain screw, this can indicate lower unit problem. Consult your Yamaha dealer. [ECM01901]



ZMU03273

1. Gear oil drain screw

2. Oil level plug

## TIP:

- If a magnetic gear oil drain screw is equipped, remove all metal particles from the screw before installing it.
- Always use new gasket. Do not reuse the removed gasket.
- (4) Remove the oil level plug and gasket to allow the oil to drain completely. **NOTICE:** Check the used gear oil after it has been drained. If the gear oil is milky or contains water or a large amount of metal particles, the gear case may be damaged. Have a Yamaha dealer check and repair the outboard motor. [ECM00714]

## TIP:

For disposal of used gear oil, consult your Yamaha dealer.

- (5) Put the outboard motor in a vertical position.
- (6) Using a flexible or pressurized filling device, inject the gear oil into the gear oil drain screw hole.

### Recommended gear oil:

YAMALUBE outboard gear oil or Hypoid gear oil

### Recommended gear oil grade:

SAE 90 API GL-4


### Gear oil quantity:

0.430 L (0.455 US qt, 0.378 Imp.qt)

(F40LET, F50LED, F50LET, F60HET)

0.670 L (0.708 US qt, 0.590 Imp.qt)

(F40NET, F70BET, FT50NET, FT60JET)



- (7) Put a new gasket on the oil level plug. When the gear oil begins to flow out of the oil level plug hole, insert and tighten the oil level plug to the specified torque.

**Tightening torque:**

7 N·m (0.7 kgf·m, 5.2 lb·ft)

- (8) Put a new gasket on the gear oil drain screw. Insert and tighten the gear oil drain screw to the specified torque.

**Tightening torque:**

7 N·m (0.7 kgf·m, 5.2 lb·ft)

EMU29318




## Inspecting and replacing anode(s)

Yamaha outboard motors are protected from corrosion by sacrificial anodes. Inspect the external anodes periodically. Remove scales from the surfaces of the anodes. Consult a Yamaha dealer for replacement of external anodes.


ECM00721

**NOTICE**

**Do not paint anodes, as this would render them ineffective.**



# Maintenance



## TIP:

Inspect ground leads attached to external anodes on equipped models. Consult a Yamaha dealer for inspection and replacement of internal anodes attached to the power unit.

EMU29324

## Checking battery (for electric start models)

EWM01903

### **WARNING**

**Battery electrolyte is poisonous and caustic, and batteries generate explosive hydrogen gas. When working near the battery:**

- Wear protective eye gear and rubber gloves.
- Do not smoke or bring any other source of ignition near the battery.


The procedure for checking the battery varies for different batteries. This procedure contains typical checks that apply to many batteries, but you should always refer to the battery manufacturer's instructions.

ECM01921

### **NOTICE**

**A poorly maintained battery will quickly deteriorate.**

- (1) Check the electrolyte level.



ZMU01810

- (2) Check the battery's charge. If your boat is equipped with the digital speedometer, the voltmeter and low battery alert functions will help you monitor the battery's charge. If the battery needs charging, consult your Yamaha dealer.
- (3) Check the battery connections. They should be clean, secure, and covered by an insulating cover. **WARNING! Bad connections can produce shorting or arcing and cause an explosion.** [EWM01913]

EMU29337

## Connecting the battery

EWM00573

### **WARNING**

**Mount the battery holder securely in a dry, well-ventilated, vibration-free location in the boat. Install a fully charged battery in the holder.**


ECM01126

### **NOTICE**

**Do not reverse the battery cables. Otherwise, the electrical parts could be damaged.**

- (1) Make sure the main switch (on applicable models) is turned to the "OFF" (off) position before working on the battery.

- (2) Connect the positive battery cable (red) to the positive (+) terminal first. Then, connect the negative battery cable (black) to the negative (-) terminal.



ZMU01811

1. Red cable
2. Black cable
3. Battery

- (3) The electrical contacts of the battery and cables must be clean and properly connected, or the battery will not start the engine.

EMU29373

## Disconnecting the battery

- (1) Turn off the battery cut-off switch (if equipped) and main switch. **NOTICE: If they are left on, the electrical system can be damaged.** [ECM01931]
- (2) Disconnect the negative cable(s) from the negative (-) terminal. **NOTICE: Always disconnect all negative battery cables (-) first to avoid a short circuit and damage to the electrical system.**

[ECM01942]

- (3) Disconnect the positive cable(s) and remove the battery from the boat.
- (4) Clean, maintain, and store the battery according to the manufacturer's instructions.

EMU38661

## Storing the battery

When storing your Yamaha outboard motor for prolonged periods of time (2 months or longer), remove the battery and store it in a cool, dry place.

Check the battery and charge it if necessary.

# Trouble Recovery

---

EMU29428

## Troubleshooting

A problem in the fuel, compression, or ignition systems can cause poor starting, loss of power, or other problems. This section describes basic checks and possible remedies, and covers all Yamaha outboard motors. Therefore some items may not apply to your model.

If your outboard motor requires repair, bring it to your Yamaha dealer.

If the engine trouble-alert indicator is flashing, consult your Yamaha dealer.

### **Starter will not operate.**

Q. Is battery capacity weak or low?

A. Check battery condition. Use battery of recommended capacity.

Q. Are battery connections loose or corroded?

A. Tighten battery cables and clean battery terminals.

Q. Is fuse for electric start relay or electric circuit blown?

A. Check for cause of electric overload and repair. Replace fuse with one of correct amperage.

Q. Are starter components faulty?

A. Have serviced by a Yamaha dealer.

Q. Is shift lever in gear?

A. Shift to neutral.

### **Engine will not start (starter operates).**

Q. Is fuel tank empty?

A. Fill tank with clean, fresh fuel.

Q. Is fuel contaminated or stale?

A. Fill tank with clean, fresh fuel.

Q. Is fuel filter clogged?

A. Clean or replace filter.

Q. Is starting procedure incorrect?

A. See page 53.

Q. Has fuel pump malfunctioned?

A. Have serviced by a Yamaha dealer.

Q. Are spark plug(s) fouled or of incorrect type?

A. Inspect spark plug(s). Clean or replace with recommended type.

Q. Are spark plug cap(s) fitted incorrectly?

A. Check and re-fit cap(s).

Q. Is ignition wiring damaged or poorly connected?

A. Check wires for wear or breaks. Tighten all loose connections. Replace worn or broken wires.

Q. Are ignition parts faulty?

A. Have serviced by a Yamaha dealer.

Q. Is engine shut-off cord (lanyard) not attached?

A. Attach cord.

Q. Are engine inner parts damaged?

A. Have serviced by a Yamaha dealer.

### **Engine idles irregularly or stalls.**

Q. Are spark plug(s) fouled or of incorrect type?

A. Inspect spark plug(s). Clean or replace with recommended type.

Q. Is fuel system obstructed?

A. Check for pinched or kinked fuel line or other obstructions in fuel system.

Q. Is fuel contaminated or stale?

A. Fill tank with clean, fresh fuel.

Q. Is fuel filter clogged?

A. Clean or replace filter.

Q. Have ignition parts failed?

A. Have serviced by a Yamaha dealer.

Q. Has alert system activated?

A. Find and correct cause of alert.

Q. Is spark plug gap incorrect?

A. Inspect and adjust as specified.

Q. Is ignition wiring damaged or poorly connected?

A. Check wires for wear or breaks. Tighten all loose connections. Replace worn or broken wires.

Q. Is specified engine oil not being used?

A. Check and replace oil as specified.

Q. Is thermostat faulty or clogged?

A. Have serviced by a Yamaha dealer.

Q. Are carburetor adjustments incorrect?

A. Have serviced by a Yamaha dealer.

Q. Is fuel pump damaged?

A. Have serviced by a Yamaha dealer.

Q. Is air vent screw on fuel tank closed?

A. Open air vent screw.

Q. Is choke knob pulled out?

A. Return to home position.

Q. Is motor angle too high?

A. Return to normal operating position.

Q. Is carburetor clogged?

A. Have serviced by a Yamaha dealer.

Q. Is fuel joint connection incorrect?

A. Connect correctly.

Q. Is throttle valve adjustment incorrect?

A. Have serviced by a Yamaha dealer.

Q. Is battery cable disconnected?

A. Connect securely.

## **Alert buzzer sounds or indicator lights.**

Q. Is cooling system clogged?

A. Check water intake for restriction.

Q. Is engine oil level low?

A. Fill oil tank with specified engine oil.

Q. Is heat range of spark plug incorrect?

A. Inspect spark plug and replace it with recommended type.

Q. Is specified engine oil not being used?

A. Check and replace oil with specified type.

Q. Is engine oil contaminated or deteriorated?

A. Replace oil with fresh, specified type.

Q. Is oil filter clogged?

A. Have serviced by a Yamaha dealer.

Q. Has oil feed/injection pump malfunctioned?

A. Have serviced by a Yamaha dealer.

# Trouble Recovery

---

Q. Is load on boat improperly distributed?

A. Distribute load to place boat on an even plane.

Q. Is water pump or thermostat faulty?

A. Have serviced by a Yamaha dealer.

Q. Is there excess water in fuel filter cup?

A. Drain filter cup.

## Engine power loss.

Q. Is propeller damaged?

A. Have propeller repaired or replaced.

Q. Is propeller pitch or diameter incorrect?

A. Install correct propeller to operate out-board at its recommended speed (r/min) range.

Q. Is trim angle incorrect?

A. Adjust trim angle to achieve most efficient operation.

Q. Is motor mounted at incorrect height on transom?

A. Have motor adjusted to proper transom height.

Q. Has alert system activated?

A. Find and correct cause of alert.

Q. Is boat bottom fouled with marine growth?

A. Clean boat bottom.

Q. Are spark plug(s) fouled or of incorrect type?

A. Inspect spark plug(s). Clean or replace with recommended type.

Q. Are weeds or other foreign matter tangled on gear housing?

A. Remove foreign matter and clean lower unit.

Q. Is fuel system obstructed?

A. Check for pinched or kinked fuel line or other obstructions in fuel system.

Q. Is fuel filter clogged?

A. Clean or replace filter.

Q. Is fuel contaminated or stale?

A. Fill tank with clean, fresh fuel.

Q. Is spark plug gap incorrect?

A. Inspect and adjust as specified.

Q. Is ignition wiring damaged or poorly connected?

A. Check wires for wear or breaks. Tighten all loose connections. Replace worn or broken wires.

Q. Have electrical parts failed?

A. Have serviced by a Yamaha dealer.

Q. Is specified fuel not being used?

A. Replace fuel with specified type.

Q. Is specified engine oil not being used?

A. Check and replace oil with specified type.

Q. Is thermostat faulty or clogged?

A. Have serviced by a Yamaha dealer.

Q. Is air vent screw closed?

A. Open the air vent screw.

Q. Is fuel pump damaged?

A. Have serviced by a Yamaha dealer.

Q. Is fuel joint connection incorrect?

A. Connect correctly.

Q. Is heat range of spark plug incorrect?

A. Inspect spark plug and replace it with recommended type.

Q. Is high pressure fuel pump drive belt broken?

A. Have serviced by a Yamaha dealer.

Q. Is engine not responding properly to shift lever position?

A. Have serviced by a Yamaha dealer.

## **Engine vibrates excessively.**

Q. Is propeller damaged?

A. Have propeller repaired or replaced.

Q. Is propeller shaft damaged?

A. Have serviced by a Yamaha dealer.

Q. Are weeds or other foreign matter tangled on propeller?

A. Remove and clean propeller.

Q. Is motor mounting bolt loose?

A. Tighten bolt.

Q. Is steering pivot loose or damaged?

A. Tighten or have serviced by a Yamaha dealer.

EMU29436

## **Temporary action in emergency**

EMU29442

### **Impact damage**

EWMM00871



**The outboard motor can be seriously damaged by a collision while operating or trailering. Damage could make the outboard motor unsafe to operate.**

If the outboard motor hits an object in the water, follow the procedure below.



- (1) Stop the engine immediately.
- (2) Check the control system and all components for damage. Also, check the boat for damage.
- (3) Whether damage is found or not, return to the nearest harbor slowly and carefully.
- (4) Have a Yamaha dealer check the outboard motor before operating it again.

EMU30685



### **Replacing fuse**

EWMM00632



**Substituting an incorrect fuse or a piece of wire could allow excessive current**

- F40L, F50L, FT50N, F60H, FT60J**



95

EMU29529

## Power trim and tilt will not operate


EWM02331

### **WARNING**

**Never get under the engine while it is tilted. Severe injury could occur if the outboard motor accidentally falls.**

If the outboard motor cannot be tilted up/down using the power trim and tilt unit, e.g. because of a discharged battery or a failure with the unit itself, the outboard motor can be tilted manually.

- (1) Stop the engine.
- (2) Loosen the manual valve screw by turning it counterclockwise until it stops.



1. Manual valve screw

- (3) Adjust the outboard motor to a navigable angle, tighten the manual valve screw clockwise, and secure the outboard motor.

EMU41472

## Water separator-alert is activated after leaving port


EWM01501

### **WARNING**

**Gasoline is highly flammable, and its vapors are flammable and explosive.**

- Do not perform this procedure on a hot or running engine. Allow the engine to cool.
- There will be fuel in the fuel filter. Keep away from sparks, cigarettes, flames or other sources of ignition.
- This procedure will allow some fuel to spill. Catch fuel in a rag. Wipe up any spilled fuel immediately.
- The fuel filter must be reassembled carefully with the O-ring, filter cup, and hoses in place. Improper assembly or replacement could result in a fuel leak, which could result in a fire or explosion hazard.

If the water separator-alert indicator blinks, perform the following procedure.



ZMU05441


1. Water separator-alert indicator

## F40L, F50L, FT50N, F60H, FT60J

- (1) Stop the engine.
- (2) Remove the top cowling.


# Trouble Recovery

- (3) Remove the plastic tie.



1. Plastic tie


- (4) Disconnect the water detection switch coupler. **NOTICE: Be careful not to get any water on the water detection switch coupler, otherwise a malfunction could occur.** [ECM01951]



1. Water detection switch coupler


- (5) Unscrew the filter cup from the filter housing. **NOTICE: Be careful not to twist the water detection switch lead when unscrewing the filter cup.**

[ECM01961]



1. Filter cup  
2. Water detection switch lead


- (6) Drain the water in the filter cup by soaking it up with a rag.  
(7) Firmly screw the filter cup onto the filter housing. **NOTICE: Be careful not to twist the water detection switch lead when screwing the filter cup onto the filter housing.** [ECM01971]  
(8) Connect the water detection switch coupler securely until a click is heard.



1. Water detection switch coupler


- (9) Fasten the water detection switch lead with the plastic tie.

# Trouble Recovery



1. Plastic tie

- (4) Remove the holder.




1. Holder

- (10) Install the top cowling.

- (11) Start the engine and make sure that the water separator-alert indicator remains off. Have a Yamaha dealer inspect the outboard motor after returning to port.


## F40N, F70B

- (1) Stop the engine.  
(2) Remove the top cowling.  
(3) Remove the cover.



ZMU07095

- (5) Disconnect the water detection switch coupler. **NOTICE:** Be careful not to get any water on the water detection switch coupler, otherwise a malfunction could occur. [ECM01951]




1. Water detection switch coupler

- (6) Unscrew the filter cup from the filter housing. **NOTICE:** Be careful not to twist the water detection switch lead when unscrewing the filter cup.


[ECM01961]

# Trouble Recovery




1. Filter cup
2. Water detection switch lead

- (7) Drain the water in the filter cup by soaking it up with a rag.
- (8) Firmly screw the filter cup onto the filter housing. **NOTICE: Be careful not to twist the water detection switch lead when screwing the filter cup onto the filter housing.** [ECM01971]
- (9) Connect the water detection switch coupler securely until a click is heard.



1. Water detection switch coupler

- (10) Fasten the water detection switch lead with the holder.



1. Holder

- (11) Install the cover.
- (12) Install the top cowling.
- (13) Start the engine and make sure that the water separator-alert indicator remains off. Have a Yamaha dealer inspect the outboard motor after returning to port.

EMU29543

## Starter will not operate

If the starter mechanism does not operate (the engine cannot be cranked with the starter), the engine can be started manually with an emergency starter rope. However, the engine cannot be started manually if the battery voltage is low. If the battery is discharged to 9 volts or below, the electric fuel pump will not operate.

EWM01023

## WARNING

- Use this procedure only in an emergency to return to the nearest port for repairs.
- When the emergency starter rope is used to start the engine, the start-in-gear protection device does not operate. Make sure the remote control lever is in neutral. Otherwise the boat could unexpectedly start to move, which could result in an accident.

# Trouble Recovery


- Attach the engine shut-off cord to a secure place on your clothing, or your arm or leg while operating the boat.
- Do not attach the cord to clothing that could tear loose. Do not route the cord where it could become entangled, preventing it from functioning.
- Avoid accidentally pulling the cord during normal operation. Loss of engine power means the loss of most steering control. Also, without engine power, the boat could slow rapidly. This could cause people and objects in the boat to be thrown forward.
- Make sure no one is standing behind you when pulling the starter rope. It could whip behind you and injure someone.
- An unguarded, rotating flywheel is very dangerous. Keep loose clothing and other objects away when starting the engine. Use the emergency starter rope only as instructed. Do not touch the flywheel or other moving parts when the engine is running. Do not install the starter mechanism or top cowling after the engine is running.
- Do not touch the ignition coil, spark plug wire, spark plug cap, or other electrical components when starting or operating the motor. You could get an electrical shock.

EMU44404


## Emergency starting engine

- (1) Remove the top cowling.
- (2) Remove the flywheel cover by removing the bolt.

F40L, F50L, FT50N, F60H, FT60J




F40N, F70B




- (3) Prepare the engine for starting. For further information, see page 53.

# Trouble Recovery




ZMU02334



ZMU05216

- (4) Insert the knotted end of the emergency starter rope into the notch in the flywheel rotor and wind the rope several turns around the flywheel clockwise.
- (5) Pull the rope slowly until resistance is felt. Give a strong pull straight out to crank and start the engine. If the engine does not start on the first try, repeat the procedure. **WARNING! Do not install the top cowling when engine is running.** [EWM00622]



ZMU07099

EMU33502

## Treatment of submerged motor

If the outboard motor is submerged, immediately take it to a Yamaha dealer. Otherwise some corrosion may begin almost immediately. **NOTICE: Do not attempt to run the outboard motor until it has been completely inspected.** [ECM00402]

|          |                                                        |          |                                              |
|----------|--------------------------------------------------------|----------|----------------------------------------------|
| <b>6</b> | 6Y8 Multifunction meters.....38                        | <b>E</b> | EC Declaration of Conformity (DoC).....5     |
| <b>A</b> | Alcohol and drugs.....2                                |          | Electric shock .....1                        |
|          | Alert indicator.....33                                 |          | Emergency equipment.....20                   |
|          | Alert system .....42                                   |          | Emergency starting engine .....100           |
|          | Anode(s), inspecting and replacing .....88             |          | Emergency, temporary action in .....94       |
|          | Anti-fouling paint.....19                              |          | Engine oil .....48                           |
|          | Avoid collisions .....3                                |          | Engine oil requirements .....18              |
| <b>B</b> |                                                        |          | Engine oil, changing .....81                 |
|          | Battery.....50                                         |          | Engine oil, filling.....46                   |
|          | Battery requirements .....16                           |          | Engine shut-off cord (lanyard).....1,48      |
|          | Battery, checking (electric start<br>models).....89    |          | Engine shut-off cord (lanyard) and clip ..27 |
|          | Battery, connecting.....89                             |          | Engine stop button .....28                   |
|          | Battery, disconnecting .....90                         |          | Engine, checking .....49                     |
|          | Battery, storing.....90                                | <b>F</b> |                                              |
|          | Boat horsepower rating .....16                         |          | Filling fuel.....51                          |
|          | Boating safety .....2                                  |          | First-time operation .....46                 |
|          | Boating safety publications .....4                     |          | Flushing device .....32,49                   |
|          | Breaking in engine .....46                             |          | Flushing power unit .....72                  |
| <b>C</b> |                                                        |          | Flushing with the flushing attachment ..70   |
|          | Carbon monoxide .....2                                 |          | Fuel filter, checking.....47                 |
|          | CE Marking / UKCA Marking.....6                        |          | Fuel filter/Water separator .....33          |
|          | Checks after engine warm up.....56                     |          | Fuel gauge .....37                           |
|          | Checks after starting engine.....55                    |          | Fuel leaks, checking for.....47              |
|          | Checks before starting engine.....47                   |          | Fuel level .....47                           |
|          | Cleaning the outboard motor.....73                     |          | Fuel level-alert indicator .....38           |
|          | Clock.....37                                           |          | Fuel requirements .....18                    |
|          | Collisions with floating or<br>submerged objects.....3 |          | Fuel system.....47                           |
|          | Components diagram .....21                             |          | Fuel tank .....24                            |
|          | Control functions, checking.....48                     |          | Fuse, replacing .....94                      |
|          | Cooling water.....55                                   | <b>G</b> |                                              |
|          | Cowling lock lever.....32                              |          | Gasoline .....2,18                           |
|          | Cruising in salt water or other<br>conditions .....68  |          | Gasoline exposure and spills.....2           |
| <b>D</b> |                                                        |          | Gear oil, changing.....87                    |
|          | Digital speedometer.....36                             |          | Gear shift lever.....26                      |
|          | Digital tachometer.....34                              |          | Greasing.....79                              |
|          |                                                        | <b>H</b> |                                              |
|          |                                                        |          | Hot parts .....1                             |
|          |                                                        |          | Hour meter .....35                           |

# INDEX

---

- I**
- Identification numbers record .....5
  - Idle speed, inspecting .....80
  - Impact damage .....94
  - Installation requirements .....16
  - Instruments and indicators .....34
- K**
- Key number .....5
- L**
- Laws and regulations .....4
  - Low battery voltage-alert indicator .....38
  - Low oil pressure alert .....43
  - Low oil pressure-alert indicator .....34,35
  - Lubrication .....71
- M**
- Main switch .....28
  - Maintenance chart 1 .....75
  - Maintenance chart 2 .....78
  - Modifications .....2
  - Mounting height .....44
  - Mounting outboard motor .....16
  - Mounting the outboard motor .....44
  - Muddy or acidic water .....19
- N**
- Neutral interlock trigger .....25
  - Neutral throttle lever .....25
- O**
- Operating engine .....52
  - Outboard motor (painted surface),  
checking .....73
  - Outboard motor disposal  
requirements .....19
  - Outboard motor safety .....1
  - Outboard motor serial number .....5
  - Overheat alert .....42
  - Overheat-alert indicator .....34,36
  - Overloading .....3
- P**
- Passenger training .....4
  - Passengers .....2
  - People in the water .....2
  - Periodic maintenance .....73
  - Personal flotation devices (PFDs) .....2
  - Power trim and tilt .....1
  - Power trim and tilt switch (bottom  
cowling) .....30
  - Power trim and tilt switch (remote  
control or tiller handle) .....29
  - Power trim and tilt system .....50
  - Power trim and tilt will not operate .....96
  - Propeller .....1
  - Propeller selection .....16
  - Propeller, checking .....85
  - Propeller, installing .....86
  - Propeller, removing .....85
- R**
- Read manuals and labels .....7
  - Remote control box .....25
  - Remote control lever .....25
  - Remote control requirements .....16
  - Replacement parts .....74
  - Replacing the engine oil filter .....83
  - Rotating parts .....1
- S**
- Sending fuel (portable tank) .....52
  - Severe operating conditions .....74
  - Shallow water .....66
  - Shifting .....56
  - Shifting (checks after engine warm up) ..56
  - Spark plug, inspecting .....79
  - Specifications .....14
  - Speedometer .....36
  - Start-in-gear protection .....17
  - Starter will not operate .....99
  - Starting engine .....53
  - Steering friction adjuster .....29
  - Stop switches .....56
  - Stopping boat .....58
  - Stopping engine .....58

|                                |     |
|--------------------------------|-----|
| Storing outboard motor .....   | 69  |
| Submerged outboard motor ..... | 101 |

## T

|                                                  |    |
|--------------------------------------------------|----|
| Tachometer .....                                 | 35 |
| Throttle friction adjuster .....                 | 27 |
| Throttle grip .....                              | 26 |
| Throttle indicator .....                         | 26 |
| Tiller handle .....                              | 26 |
| Tilt lock mechanism .....                        | 32 |
| Tilt support lever .....                         | 32 |
| Tilting up and down .....                        | 62 |
| Top cowling, installing .....                    | 49 |
| Top cowling, removing .....                      | 47 |
| Transporting and storing outboard<br>motor ..... | 69 |
| Trim meter .....                                 | 35 |
| Trim rod (tilt pin) .....                        | 31 |
| Trim tab with anode .....                        | 31 |
| Trimming outboard motor .....                    | 59 |
| Trip meter .....                                 | 37 |
| Trolling .....                                   | 58 |
| Troubleshooting .....                            | 91 |

## U

|                      |    |
|----------------------|----|
| Use, your data ..... | 11 |
|----------------------|----|

## V

|                                      |    |
|--------------------------------------|----|
| Variable trolling RPM switches ..... | 30 |
| Voltmeter .....                      | 38 |

## W

|                                                                |    |
|----------------------------------------------------------------|----|
| Warming up engine .....                                        | 56 |
| Warning labels .....                                           | 7  |
| Water separator-alert is activated<br>after leaving port ..... | 96 |
| Weather .....                                                  | 4  |
| Wiring and connectors, inspecting .....                        | 84 |

## Y

|                                                   |    |
|---------------------------------------------------|----|
| Yamaha Security System (Y-COP/<br>Optional) ..... | 24 |
| Yamalube .....                                    | 84 |



Printed in Japan  
December 2024-2.1 × 1 NK